



CIVINCO

SA500 & SA1000 G3 v3

Software manual
Installation guide
Tuning guide

Dataset ID 205



SOFTWARE MANUAL

SA500G3 / SA1000G3 v3

SOFTWARE MANUAL SA500G3 / SA1000G3 V3	2
NEWS 2010, (G3v3 ID205)	4
NEWS 2009 (G3v2 ID204)	4
Introduction	4
Function overview SA500G3 & SA1000G3 v3	6
System overview SA500G3	6
System overview SA505 G3 v3	7
System overview SA1000G3 v3	7
System overview SA1005G3 v3	7
Which system should you select	8
IMPORTANT	8
General controls in BCLab	9
USB Status / Todos Status	9
File Description	10
Use of all pages with tables	10
How to change value in current cell	11
FUEL	13
Main fuel map based on load and rpm	13
Fuel map 2 & 3	15
Fuel based on AFR	18
Ignition	19
Ignition based on RPM & Load	19
1st ignition compensation based on load	20
2nd ignition compensation based on load	20
PWM1-4, Boost control and idle control	21
Boost/PWM1 based on RPM	21
Boost depending on analog input signal and closed loop	21
Boost/PWM1 compensation map based on load	22
PWM2 based on coolant temperature (idle control)	22
Settings – Box settings	23
Setting – Engine setup	23
Setting – Fuel map	27
Setting - Ignition	31
Setting - Idle	33
Setting – AFR control	34
Setting – AFR Control Auto tune	35
Setting – Temperature compensation	36
Setting – Battery voltage and start up compensation	37
Setting – Limits and warnings	38



Setting – PWM and Boost control	39
Setting – Digital 1&2 in	41
Inställning – Launch control & ALS	42
Setting – Analog	45
Setting – Digital output	46
Logging	48
Log menu	48
Logging with external display	52
Log settings	52
Power calculation	54
Main menu for logging - File	55
Oscilloscope logging	56
Main menu	57
menu – File	57
menu – Edit	57
menu – Communication	57
menu – View	58
menu – Settings	58
menu-Sensor settings	59
menu - Sensor Viewer	60
menu – Help	61
Shortcuts	62
File format	62
Wordlist and definitions	63
2.5D	63
PWM signals	63
INSTALLATION OF SA500G3 & SA1000G3	67
Installing the system	67
Connector specification SA500 G3 v3	69
Connector specification BC1000S G3	70
The box front panel	72
Crank sensor	73
Cam sensor	73
Fuel injectors	73
Ignition coils	73
Firing order	74
Igniter	77
Boost control valve	77
Idle control valve	77
Oxygen sensor	77
Coolant temperature sensor	78
Intake air temperature sensor (IAT)	78
Throttle position sensor (TPS)	78
MAP-sensor	79
MAF-sensor	79



ASD/DME-relay	79
Knock sensor	80
TUNING WITH SA500G3/1000S G3	81
Check all the input signals	81
Autosetup & First start up	82
Create your first tuning parameters	88
First engine startup	91

NEWS 2010, (G3v3 ID205)

1. [ALS \(Anti lag system\)](#) to keep up boost at part load and engine brake.
2. More advanced launch control with start-RPM, launch-RPM-limit
3. First cell in fuel and ignition map, totally free to set to any value
4. Extra 3:rd fuel compensation map
5. Extra 3:rd ignition compensation map
6. Extra PWM1 compensation map, to have TPS dependent boost control
7. Extra RPM limit dependent on coolant or digital input
8. Selectable range for the internal MAP sensor. 0-4 bar or 0-2 bar
9. Asjustable injector dead time, to have more accurate compensation maps.
10. Support of more engine types like all with 36-1 crank, Nissan 200, Toyota Supra and Honda R1

NEWS 2009 (G3v2 ID204)

1. Start up guide which guides you through all steps to get a base map ready for your first start attempt.
2. Auto tune, long term adaptiv fuel.
3. Tunable extra idle air at engine start
4. Tunable temperature to start AFR-control.
5. Deceleration fuel
6. In the log program you can open and compare to log files.
7. BCLab's windows can be resized to full screen.

INTRODUCTION

With Civinco's Engine management system SA500G3 or SA1000G3 you will easily optimize your engine. The system controls all the critical parameters like fuel, ignition, boost and warning systems. All the data are stored at smart card memories and can easily be changed during run. Civinco AB in Sweden can help you with most things in car tuning via a broad network of resellers worldwide.

Civinco offers two families of engine management systems; [InSeries systems](#) which works together with the stock ECU/PCM, and [Stand Alone](#) systems for more advanced tuning were



you replace the stock ECU/PCM.



FUNCTION OVERVIEW SA500G3 & SA1000G3 v3

- 3D fuel map with selectable number of cells up to 18*19 cells
- 2 fuel maps, which can be combined as preferred.
- Fuel compensation
 - Extra load sensor
 - Coolant temp, Air temp, Battery voltage
 - Acceleration enrichment
- Ignition map based on 21 RPM cells, and selectable load sensor with 33 cells.
- Sequential fuel timing
- Over 25 different cam and crank sensor configurations (60-2, 22-2, 24, 36-2 etc)
- Most ignition orders for 4, 6 and 8 cylinders
- AFR closed loop
 - Short and long term adaptive
- Launch control for boost spool up
 - Tunable Ignition retard, Rev limit and extra fuel
- ALS function for keeping boost during part load
 - Tunable Ignition retard, Rev limit, extra air and extra fuel
- Idle control
 - Ignition
 - Idle control valve with 1 or 2 PWM
- Boost control
 - Open or closed loop (PID) via PWM
- Warning systems and error codes
 - RPM limiter
 - Fuel cut at over boost
- ASD/DME relay output to control supply voltage to fuel pump etc
- All out and input can be reconfigured for different functions
- Uses all original sensors, so no extra sensors are needed to be bought
- USB communication with PC
- Log up to 75 engine and sensor signals to PC via USB

SYSTEM OVERVIEW SA500G3

- 4 fuel channels for high ohm injectors
- 2 ignition channels for external igniters
- 6 analog inputs
 - MAP
 - Coolant temp
 - Throttle position*
 - AFR*
 - IAT / AUX1*
 - 12V battery / AUX2*
- 4 digital inputs
 - Cam sensor
 - Crank sensor
 - Launch control
 - Ignition cut or Speed



- 3 digital output
 - ASD, fan control, tach output, gearing indicator, error code lamp, programmable output based on RPM and analog input
 - +5V voltage supply for external sensors
- 2 PWM output for boost control, idle control, VTEC, Vanos**

SYSTEM OVERVIEW SA505 G3 v3

- For Volvo and Audi 5 cylinder engines with distributor
- 5 fuel channels
- 1 ignition channel
- All other like SA500G3

SYSTEM OVERVIEW SA1000G3 v3

- 8 fuel channels for high ohm injectors
- 4 ignition channels for external igniters
- 10 analog inputs
 - MAP
 - Coolant temp
 - Throttle position*
 - AFR*
 - IAT / AUX1*
 - 12V battery / AUX2*
 - 2 extra inputs for options AUX3 / AUX4
- 6 digital inputs
 - Cam sensor
 - Crank sensor
 - Launch control
 - Ignition cut or Speed
 - 2 extra inputs for options
- 5 digital output
 - ASD, fan control, tach output, gearing indicator, error code lamp, programmable output based on RPM and analog input
 - +5V voltage supply for external sensors
- 4 PWM output for boost control, idle control, VTEC, Vanos**

** can be used to log other signals as well.*

*** all outputs can be used to control selectable functions*

SYSTEM OVERVIEW SA1005G3 v3

- For Volvo and Audi 5 cylinder engines with coil on plug
- 5 fuel channels
- 5 ignition channel
- All other like SA1000G3



WHICH SYSTEM SHOULD YOU SELECT

1. What type of cam and crank signal?
 - Inductive or digital
SA500G3/1000G3 supports both types, but inductive sensors could need some extra tuning.
2. Number of pulses per rev for the cam and crank sensor
 - SA500G3/1000G3 supports more than 25 different combinations
3. Number of cylinders, ignition coils and ignition principle?
 - 4-8 cyl with 1-4 coils
SA500G3 supports up to 4 cylinders and 2 coils
SA1000G3 supports up to 8 cylinders and 4 coils

1) Installation of BCLab

[Part 1](#) of this manual is PC-software manual and describes all the system functions and how to tune the car.

Installation:

Insert the CD in the computer and start the installation by double click at setup.exe.
Follow the instructions.

2) Installation of system

[Part 2](#) of this manual describes how to install the system to the engine, and what you need to think about.

3) Tuning of engine

[Part 3](#) describes some tuning basics and strategies to create a first time start up map.

IMPORTANT


Civinco are responsible that the engine management system is working correctly at delivery, presupposed it has been correctly installed.

Civinco offers a 10 year warranty.

Civinco does not take responsibility for damage on engine, car or person in connection to the use of Civinco's system



GENERAL CONTROLS IN BCLAB



USB STATUS / TODOS STATUS

There are three ways to communicate with your box or TuneCards. In the upper left corner you will see the chosen communication mode. You may switch between these in the menu Edit-Toggle Interface or by pressing Ctrl+T.

- USB serial communication between PC and BC-box
- Chipdrive connected to the PC that read/writes TuneCards
- Use of the BC-box as a TuneCard reader when the BC-box is connected via USB

Direct communication with the system



Handles the USB-communication with connected BC500/BC1000G3.

Write - Saves the BCLab current tuning to the BC-box



Verify - Verifies that the BC-box tuning is the same as the BCLab tuning


Read - Reads the BC-box tuning and displays them in BCLab

Info - Reads some general information from the BC-box

Live Data changes during logging

If you do changes in the mapping or settings during logging, these changes will take part immediately. You do not have to press "Write" for the changes. This makes it easier to make changes in the mapping and immediately see the changes in the log file. I.e if you make fuel adjustment, you can see the AFR change right away.

Todos card reader



Handles the TuneCard reader if it is connected to the PC.

Find Writer - The program tests the connection with the Todos reader

Write Card - Saves the BCLab current tuning to the TuneCard



Read Card - Reads the TuneCard tuning and displays them in BCLab

FILE DESCRIPTION

This area in the lower left corner can be used to write text to describe the new settings. The text is saved at the same time as you save the settings to the harddrive. They are not saved to the TuneCard or when you write to the box.

USE OF ALL PAGES WITH TABLES

Table Control




All BCLab pages that have tuning tables also have a "Table Control" box. This is used to easily adjust the tuning values in the table. You can also use this to edit several tuning values at the same time by marking the desired values. To mark all table values click on "Deg", "ms" or "%" in the table upper right corner.



- "+" increase the selected values 1 step
- "-" decrease the selected values 1 step
- increase slope of the selected values to the right
- decrease slope of the selected values to the right
- decrease slope of the selected values to the left
- increase slope of the selected values to the left
- decrease slope of the selected values in the bottom
- increase slope of the selected values in the bottom
- decrease slope of the selected values in the top
- increase slope of the selected values in the top
- "Scale%" Scales the marked values with the selected % value
- "Set to" Sets the marked values to the selected value.
- "min", "max" Informs the user of the possible values in this table

You can also mark a cell and write the value directly into the box without using the commands above.

HOW TO CHANGE VALUE IN CURRENT CELL



If the engine is running (with or without logging running), an extra window will appear which makes it possible to adjust fuel and ignition in the current cell without having to mark it with the mouse.

You have to be close enough the center of the cell to be able to adjust it, to prevent from adjusting wrong cell.



Smoother data

There are two functions which evens out the data in 3D tables to make it easier to remove unwanted dip and tops. You can even out in horizontal and in vertical direction.

- **"Smoother Rows"**

If you have values on the first and last row in a selection, and want to even it out on the rest of the rows, you just press "Smoother rows"

	0	500	1000	1500
0.13	2.02	2.02	2.02	2.02
0.21	2.02	2.02	2.02	2.02
0.29	2.02	2.02	2.02	2.02
0.36	2.02	2.02	2.02	2.02
0.44	2.02	2.02	2.02	2.02
0.52	2.02	2.02	2.02	2.02
0.60	10.0	10.0	10.0	10.0

results in

	0	500	1000	1500
0.13	2.02	2.02	2.02	2.02
0.21	3.1	3.1	3.1	3.1
0.29	4.5	4.5	4.5	4.5
0.36	5.8	5.8	5.8	5.8
0.44	7.2	7.2	7.2	7.2
0.52	8.6	8.6	8.6	8.6
0.60	10.0	10.0	10.0	10.0

- **"Smoother Cols"**

If you have values on the first and last columns in a selection, and want to even it out on the rest of the columns, you just press "Smoother columns"

	0	500	1000	1500
0.13	0.0	0.0	0.0	10.0
0.21	0.0	0.0	0.0	10.0
0.29	0.0	0.0	0.0	10.0
0.36	0.0	0.0	0.0	10.0
0.44	0.0	0.0	0.0	10.0
0.52	0.0	0.0	0.0	10.0
0.60	0.0	0.0	0.0	10.0

results in

	0	500	1000	1500
0.13	0.0	3.3	6.7	10.0
0.21	0.0	3.3	6.7	10.0
0.29	0.0	3.3	6.7	10.0
0.36	0.0	3.3	6.7	10.0
0.44	0.0	3.3	6.7	10.0
0.52	0.0	3.3	6.7	10.0
0.60	0.0	3.3	6.7	10.0



FUEL

Before you start to tune the fuel, you need to decide how the basic principles of your tuning should be, load sensor, ignition order, number of fuel cells etc.

Choice of fuel tables

SA500G3/1000G3 handles up to 3 fuel tables:

- 2 fuel maps - 3D Main MAP and 2nd Fuel MAP.
- 3 fuel maps - 3D Main MAP and 2 different fuel compensation maps

The user can select which load sensor to use for respective fuelmap.

Normal alternative for 2 fuel maps


- 3D Main - MAP & 2nd fuel – not used
- 3D Main - MAP & 2nd fuel – Throttle position
- 3D Main – Throttle position & 2nd fuel - MAP

RPM and load resolution (number of cells)

You can adjust the number of load and rpm cells you want to have in the fuel map. You can also select which load and rpm values to use in each cell, to make sure you map exactly as you desire. If you already have made a map and want to change axis in some way, you can save this map and convert it to the new axis setting.

These settings are made under [Settings – fuel maps](#).

MAIN FUEL MAP BASED ON LOAD AND RPM



For each rpm and each load you set the desired fuel pulse length.




In this example at 3000 rpm and 1.11 bar MAP, the engine gets 16.3 ms fuel.
The system linearize between the cells, so at 3250 rpm, the engine gets 16.75 ms fuel.

3D Table control

All cells can be adjusted in “group” to more easily adjust and change the slope of the fuel.
See also [Table Control](#)

View 3D MAP

Opens a separate window and shows the 3D graph visualizing the fuel setting.



3D color control

Controls how the fuel values should be represented in colors.

Verify coloring

When using “Verify” the system compares the fuel map with the current map in the SA500 box. If there is a difference, the difference is represented in different colors depending on how large the difference is.



View fuel verify difference

	0	500	750	1000	1250	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	8000	8063
0.01	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
0.02	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
0.09	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
0.16	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	-0.1	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
0.22	0.0	0.0	0.0	0.0	-0.1	-0.7	-0.8	-0.7	-0.3	-0.2	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
0.29	0.0	0.0	0.0	-0.3	-0.5	-0.7	-0.5	-0.5	-0.2	-0.1	-0.2	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
0.35	0.0	0.0	0.0	-0.6	-0.1	-0.7	-0.5	-0.8	-0.2	-0.2	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
0.42	0.0	0.0	0.0	-0.2	-0.3	-1.1	-0.8	-0.7	-0.4	-0.2	0.0	0.0	0.0	0.0	-0.2	0.0	0.0	0.0	0.0
0.48	0.0	0.0	0.0	0.0	-0.8	-1.2	-0.9	-1.1	-0.2	-0.4	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
0.55	0.0	0.0	0.0	0.0	0.0	-0.6	-0.5	-1.2	-0.8	-0.9	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
0.61	0.0	0.0	-0.4	-0.2	-0.9	-1.2	-1.2	-1.7	-1.1	-0.3	-0.3	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
0.68	0.0	0.0	0.0	-0.5	-0.3	-1.3	-0.3	-1.6	-0.7	-0.4	-0.9	-1.0	-1.5	-1.4	0.0	0.0	0.0	0.0	0.0
0.74	-0.5	-0.5	-0.5	-0.5	-0.5	-0.3	-1.6	-1.3	-0.7	-1.3	0.0	0.0	0.0	0.0	-0.4	0.0	0.0	0.0	0.0
0.81	-1.4	-1.4	-1.4	-1.4	-1.4	-1.5	-0.8	-1.7	-1.4	-1.1	-0.7	-0.7	-0.7	-0.7	0.0	0.0	0.0	0.0	0.0
0.87	-1.4	-1.4	-1.4	-1.4	-1.8	-2.3	-2.4	-1.9	-2.0	-1.3	-1.7	-0.7	-1.3	-1.6	0.0	0.0	0.0	0.0	0.0
0.94	-1.4	-1.4	-1.4	-1.4	-1.4	-1.4	-2.4	-3.6	-3.2	-3.0	-2.6	-2.2	-2.4	-1.7	-1.3	0.0	0.0	0.0	0.0
1.00	-1.1	-1.1	-1.1	-1.1	-1.1	-1.2	-0.5	-2.7	-3.1	-2.8	-2.3	-2.3	-2.3	-2.3	-2.3	0.0	0.0	0.0	0.0
1.04	17.8	-2.2	-2.2	-2.2	-2.2	-2.2	-2.2	-2.6	-2.0	-2.6	-2.6	-2.6	-2.6	-2.6	-2.6	-2.6	-2.6	-2.6	-2.6

FUEL MAP 2 & 3

In the SA-system you can choose from:

- 2 fuel maps - 3D Main MAP and 2nd Fuel MAP.
- or
- 3 fuel maps - 3D Main MAP and 2 different fuel compensation maps

Extra 2.5D fuel map


The normal reason to use two fuel maps is if you have a turbo- or supercharged engine that is modified in a “extreme” way so there is not much vacuum in idle and maybe very choppy MAP signal on high load. The more extreme engine needs to be tuned at throttle position (main map), but also needs compensation when the boost kicks in (2nd fuel map).

Fuel map 2 are of the type [2.5D](#), i.e. you tune load and rpm separately. You set desired fuel depending on load, and then how you want this fuel to be compensated by the rpm. Click F6 to see the resulting 3D-graph.

See page [Setting – fuel map](#).



Fuel map 2 based on load



First tune how fuel should depend on load. Normally more fuel at increased load.

Table data

In the left column the input voltage for selected sensor is shown.

The value in the middle column varies depending on which kind of sensor you choose in ["Used Analog Sensor"](#).

In the column to the right, you choose fuel (in mille seconds) depending on load.

Fuel map 2 based on rpm





Table data

In the column to the right you enter the fuel compensation depending on the RPM, compared to the value you entered in the "Fuel Load"-tab. Example: if you have a specific load which specify 3 ms extra fuel and you have entered 50% at 2000 rpm and 150% at 3000rpm in this RPM table, the resulting fuel will be 1.5 ms at 2000rpm and 4.5 ms at 3000rpm.




Compensation map 1&2



Instead of choosing 1 extra complete fuel map, you can select to have 2 extra compensation maps, which compensate the fuel in the main map with a percentage


One example is to let the main fuel map be controlled by TPS, and then make a MAP compensation at boost.



Another example is if you also want to compensate the fuel depending on IAT or exhaust gas temperature.



FUEL BASED ON AFR



If you have selected to use closed loop wide band AFR control, you can in this table specify different AFR at different load. See also [Settings – AFR closed loop](#).



IGNITION

Before you start to tune the ignition, you need to decide how the basic principles of your tuning should be, load sensor, ignition order, number of fuel cells etc.

Choice of load sensor

SA500G3/1000G3 handles 3 ignition maps - 3D Main ignition and 1st Ignition compensation and 2nd ignition compensation.

The user can select which load sensor to use for respective MAP. These settings are made under [Settings – ignition maps](#).

Normal alternative

- 3D Main - MAP & 1st & 2nd ignition – not used
- 3D Main - MAP & 1st ignition – IAT or knock sensor
- 3D Main – Throttle position & 1st ignition – MAP & 2nd Ignition compm - IAT

RPM and load resolution (number of cells)

You can adjust the number of load and rpm cells you want to have in the ignition map. You can also select which load and rpm values to use in each cell, to make sure you map exactly as you desire. If you already have made a map and want to change axis in some way, you can save this map and convert it to the new axis setting.


IGNITION BASED ON RPM & LOAD

The screenshot shows the CIVINCO SA500/SA1000G3 Interface Software. The main window displays the 'Ignition main 3D map' table, which is a 16x16 grid of values. The table is titled 'Set fuel depending on RPM and Load'. The columns represent RPM values from 500 to 7500, and the rows represent load values from 0.25 to 2.44. The table is color-coded, with red indicating higher values and blue indicating lower values. The 'Ignition Load sensor' is set to 'MAP - MAP MPX 2.5bar (bar)'. Below the table, there are controls for '3D Table Control' (Scale %, Set value, 3D View, Smoothen rows, Smoothen columns) and '3D color control' (Colored, Gray scale, Color scheme, Verify coloring, Verify limit, Lower in box, Higher in box). The bottom of the window shows tabs for '3D Main Ignition', '3rd Ignition compensation', and '2nd Ignition compensation', with sub-tabs for 'General', 'Ignition', 'Fuel', and 'PWM/Boost/Idle'.

Normally you need more advanced timing at higher RPM. This used to be controlled by centrifugal weights in the distributor.




1ST IGNITION COMPENSATION BASED ON LOAD



There are 2 independent ignition maps for use with two different load signals. This can be used to retard ignition at high intake air temperature. It can also be used with a knock sensor that can retard the ignition. You can adjust the timing ± 25 degrees.

2ND IGNITION COMPENSATION BASED ON LOAD



There are 2 independent ignition maps for use with two different load signals. This can be used to retard ignition at high intake air temperature. It can also be used with a knock sensor that can retard the ignition. You can adjust the timing ± 25 degrees.




PWM1-4, BOOST CONTROL AND IDLE CONTROL

The BC-system has 4 independent PWM outputs which can be mapped depending on load or rpm. PWM1 can also be used for closed loop boost control.

Also see chapter [PWM-signals](#) to better understand what a PWM-signal is.


To set desired PWM function see page [Settings - PWM](#)

BOOST/PWM1 BASED ON RPM



Here you can set desired PWM-duty cycle depending on load.


BOOST DEPENDING ON ANALOG INPUT SIGNAL AND CLOSED LOOP



With this tab, you can set which boost you desire depending on an analog input signal for instance throttle position. With this you can create more “economic” setting to save the turbo charger and get a smother response.




BOOST/PWM1 COMPENSATION MAP BASED ON LOAD



With PWM1 compensation can you control which boost you like depending on an extra load sensor, example TPS.

This setting above gives you a less boost until you press the throttle harder. which gives you a smoother transition between no boost and boost, and also more control which is critical in racing.

PWM2 BASED ON COOLANT TEMPERATURE (IDLE CONTROL)



If you want to control the idle valve, the best is to use PWM2. If you have set the engine temperature as load signal for one of the PWM-outputs, you can select desired PWM depending on temperature. If you connect the PWM-output to an idle engine, you can adjust the idle rpm depending on engine temperature.



SETTINGS – BOX SETTINGS

SETTING – ENGINE SETUP

Tuning settings

Engine configuration. Current selection: Volvo 740 88b and later

Current: 9. EX: Volvo 740 88b and later CRANK: 60-2 CAM:0 TDC:0 IG: 1-3-4-2 4 cyl

4 cyl
distributor
FUEL: Semiseq 4ch
CRANK: 60-2

CAM:0
CAM:0
TDC:0
IG: 1-3-4-2

A-1:2:3:4

EDIT CANCEL APPLY CHANGE

Crank and cam signal settings

Crank sensor trigger slope
☒ Negative ☐ Positive

Cam sensor trigger slope
☒ Negative ☐ Positive

Go to digital logging

Crank sensor teeth between missing pulse and 51 deg BTDC marking
5 teeth

Crank sensor Ignition offset (fine tuning)
3.0 deg

Angle between missing pulse and TDC marking
84.0 deg

Example: deg

Crank sensor teeth between missing pulse and Fuel pulse start
22 teeth

Recommended: 17 teeth

Positive slope
Negative slope (the signal goes down after the 2 longer pulses)

Turn the engine to 51 deg BTDC. Count how many teeth there are between sensor and missing pulse.

OK

Engine configuration

Choose which cam and crank sensor setup your engine has. This is one of the most fundamental settings to give the SA-system information about number of cylinders and ignition order etc.

There is a guide where you first select numbers of cylinders and then work through the guide until you have selected all important datas. You can also skip this guide, and select the right setting directly.



Engine types supported:

Cyl.	System	Crank1	Cam1	TDC	Ignition	Firing_order	Car_example
2 cyl	SA500	CRANK: 36-	CAM:0	TDC:0	waste fire	IG: 1-2	EX: Victory Freedom
2 cyl	SA500	CRANK: 60-	CAM:0	TDC:0	waste fire	IG: 1-2	EX: Victory Gen1 -01
4 cyl	SA500	CRANK: 0	CAM:4	TDC:0	waste fire	IG: 1-3-4-2	EX: Mazda Miata Gen1 -98
4 cyl	SA500	CRANK: 0	CAM:36	TDC:0	waste fire	IG: 1-3-4-2	EX: Nissan 200SX
4 cyl	SA1000	CRANK: 0	CAM:24	TDC:0	distributor	IG: 1-3-4-2	EX: TOYOTA CELICA CS
4 cyl	SA500	CRANK: 130	CAM:0	TDC:1	distributor	IG: 1-3-4-2	EX: Porsche 944 -83-87
4 cyl	SA500	CRANK: 22-	CAM:1	TDC:0	distributor	IG: 1-3-4-2	EX: VOLVO 360 Special
4 cyl	SA500	CRANK: 36-	CAM:1	TDC:0	distributor	IG: 1-3-4-2	EX: Ford Escort RS Cosworth -94 Stock
4 cyl	SA500	CRANK: 36-	CAM:1	TDC:0	waste fire	IG: 1-3-4-2	EX: Ford Escort RS Cosworth -94 WF
4 cyl	SA500	CRANK: 36-	CAM:1	TDC:0	distributor	IG: 1-3-4-2	EX: Civinco 4cyl, distributor
4 cyl	SA500	CRANK: 36-	CAM:0	TDC:0	distributor	IG: 1-3-4-2	EX: Civinco 4cyl, semisequential
4 cyl	SA500	CRANK: 36-	CAM:1	TDC:0	waste fire	IG: 1-3-4-2	EX: Civinco 4cyl, waste fire
4 cyl	SA500	CRANK: 4	CAM:2	TDC:0	distributor	IG: 1-3-4-2	EX: Ford Sierra RS Cosworth -89 Stock
4 cyl	SA500	CRANK: 4	CAM:2	TDC:0	waste fire	IG: 1-3-4-2	EX: Ford Sierra RS Cosworth -89 WF
4 cyl	SA500	CRANK: 4	CAM:3	TDC:0	waste fire	IG: 1-3-4-2	EX: Mazda Miata Gen2 99-
4 cyl	SA500	CRANK: 60-	CAM:1	TDC:0	distributor	IG: 1-3-4-2	EX: Audi 1.8T
4 cyl	SA1000	CRANK: 60-	CAM:1	TDC:0	direct fire 4ch	IG: 1-3-4-2	EX: Audi 1.8T -96
4 cyl	SA500	CRANK: 60-	CAM:0	TDC:0	distributor	IG: 1-3-4-2	EX: Volvo 740 88b and later
4 cyl	SA500	CRANK: 60-	CAM:0	TDC:0	waste fire	IG: 1-3-4-2	EX: Volvo 740 88b and later, modified WF
4 cyl	SA500	CRANK: 60-	CAM:1	TDC:0	waste fire	IG: 1-3-4-2	EX: Volvo S40 -03
4 cyl	SA500	CRANK: 8	CAM:1	TDC:0	waste fire	IG: 1-3-4-2	EX: Yamaha R1
5 cyl	SA505	CRANK: 270	CAM:1	TDC:1	distributor	IG: 1-2-4-5-3	EX: Audi S2, 5 cyl -92
5 cyl	SA1005	CRANK: 270	CAM:1	TDC:1	direct fire	IG: 1-2-4-5-3	EX: Audi S2, 5 cyl -95
5 cyl	SA505	CRANK: 60-	CAM:1	TDC:0	distributor	IG: 1-2-4-5-3	EX: Volvo 850, 5-cyl
5 cyl	SA1005	CRANK: 60-	CAM:1	TDC:0	direct fire 5ch	IG: 1-2-4-5-3	EX: Volvo S60, V70, 5-cyl, (w/o E-throttle)
6 cyl	SA1000	CRANK: 0	CAM:24	TDC:0	waste fire	IG: 1-5-3-6-2-4	EX: TOYOTA Supra MK3, MK4
6 cyl	SA500	CRANK: 116	CAM:0	TDC:1	distributor	IG: 1-5-3-6-2-4	EX: BMW 6 cyl old M5
6 cyl	SA500	CRANK: 36-	CAM:0	TDC:0	distributor	IG: 1-4-2-5-3-6	EX: Ford 6 Cyl, distributor
6 cyl	SA1000	CRANK: 4	CAM:2	TDC:0	waste fire	IG: 1-4-2-5-3-6	EX: Ford 6 Cyl, waste fire
6 cyl	SA500	CRANK: 60-	CAM:0	TDC:0	distributor	IG: 1-5-3-6-2-4	EX: BMW 525 -88 with distributor
6 cyl	SA1000	CRANK: 60-	CAM:1	TDC:0	waste fire	IG: 1-5-3-6-2-4	EX: BMW M3 3.0lit, BMW 2.5lit
8 cyl	SA1000	CRANK: 3-4	CAM:82	TDC:0	distributors	IG: 1-8-4-3-6-5-7-2	EX: Batmobile
8 cyl	SA1000	CRANK: 36-	CAM:1	TDC:0	distributors	IG: 1-8-4-3-6-5-7-2	EX: Civinco 8cyl, distributor x2
8 cyl	SA1000	CRANK: 36-	CAM:1	TDC:0	waste fire	IG: 1-5-4-2-6-3-7-8	EX: Civinco 8cyl, waste fire
8 cyl	SA1000	CRANK: 60-	CAM:1	TDC:0	waste fire	IG: 1-5-4-8-6-3-7-2	EX: BMW 740 V8
8 cyl	SA1000	CRANK: 60-	CAM:1	TDC:0	waste fire	IG: 1-8-4-3-6-5-7-2	EX: Chevrolet V8
8 cyl	SA1000	CRANK: 60-	CAM:1	TDC:0	waste fire	IG: 1-3-7-2-6-5-4-8	EX: PORSCHE 928, converted to 60-2

Cam and Crank signal settings

Crank sensor trigger slope

Select if the system should use the positive or the negative slope of the crank signal.

If you have a trigger wheel with missing tooth, the signal can look like this, when observed by oscilloscope or BC-systems high speed logging:



In alt 1-2 you should select the **negative slope**, because the signal goes down right after the two longer pulses.



Alt 3:



Alt 4:



In alt 3-4 you should select the **positive slope**, because the signal goes up right after the two longer pulses.

Cam sensor trigger slope

Select if the system should use the positive or the negative slope of the cam signal. Avoid selecting a cam flank that is close to the end of the missing pulse.

Crank sensor teeth

Select how many crank teeth there are between missing pulse and 51 degrees before top dead center of No:1 cylinder.

When the system for the first time sees the missing tooth, it must now exactly where at the rev it is. The BC-system starts it's timing at 51 degrees before top dead center, because the ignition can be trigged from 51° to 0° before TDC. That's why you need to specify the number of tooth between the missing pulse and the 51° before TDC.

Example with 36-2 trigger wheel:

Missing tooth has just passed the sensor	Engine at 51 deg BTDC, and it has passed 4 teeth in front of the sensor.	At TDC

Forbidden teeth

For each crank sensor setting, there are a few teeth that are forbidden as base for ignition and fuel. The program automatically detects this and gives a warning if you select a forbidden tooth

Crank sensor offset

If there is not a whole number of crank sensor teeth before the “magic” 51 deg BTDC, this is a fine tuning of the ignition setting. In the example above it could have been 4 ½ tooth. To make sure you have the right timing, lock the ignition tables to for instance 10 deg all over, and test with a timing lamp that the ignition is really shoot at right spot.




Crank sensor fuel teeth

Select how many crank teeth there are between missing pulse and when you like to start the fuel pulse.

This is important if you want to optimize the fuel at idle and low load when the fuel pulses are short. At full load, the injectors are open most the time anyway and therefore this is not as critical.

BCLab automatically gives a recommendation of which tooth that is the best, 50 degrees after the intake valve is opened.



In this example with 36-2 crank sensor, it is optimal to select about 50 pulses, because it is first one whole rev + about 14 tooth before the intake valve is starting to opening. This is valid if you have a sequential system.

If you do not have a cam sensor and therefore using a semi sequential system, so you should select only 14 teeth. (Because the system is reset every revolution, and shoots fuel every rev.

Model preset

Set which software version of BC-system you use. Normally you select the one with highest number. If you try to use the wrong one, the BC-system will give you error message

BC Digital I/O mode

Always "Stand Alone" for stand alone systems.

Box settings

Open the box settings window, from where all the fundamental engine settings are made. See also [Settings – box settings](#).



SETTING – FUEL MAP

Tuning settings

3D RPM and MAP axis set
 RPM resolution (set all) rpm
 MAP resolution (set all) bar
 Decrease value Increase value Insert row

3D fuel options
 Main 3D fuel map
 3D map size
 2nd/3rd Fuel function
 2nd Fuel map
☒ 0-250% ☐ 0-500%
 3rd Fuel map
☒ 0-250% ☐ 0-500%

Fuel injector dead time
 Injector dead time ms

Load	RPM
0.09	0
0.13	500
0.21	1000
0.36	1500
0.44	2000
0.6	2500
0.76	3000
0.91	3500
1.07	4000
1.23	4500
1.38	5000
1.54	5500
1.7	6000
1.85	6500
2.01	7000
2.17	7500
2.33	8000
2.36	9000
	9000

Convert map to new axis settings
 1) Click to save current fuel map
 2) Adjust the RPM and MAP resolution, sensor definitions etc.
 3) Click to convert saved map

Digital inputs Analog settings Limits / Warnings Engine setup Fuel acceleration **Fuel settings** Digital outputs
 Launch / ALS Ignition settings PWM outputs AFR control Idle settings Temp corrections Start up OK

3D fuel options

Main 3d fuel map sensor

Select main load sensor to use as base for the fuel map.

3d map size

Select the size of the fuel map. Number of rpm cells x number of load cells

There are 3 different sizes

- 19 rpm x 18 load
- 21 rpm x 16 load
- 25 rpm x 13 load
- 18 rpm x 11 load *
- 16 rpm x 21 load
- 13 rpm x 25 load
- 11 rpm x 11 load *
- 15 rpm x 13 load *

* this resolution is also selectable for ignition, so that you can get same resolution for both fuel and ignition.

2nd & 3rd fuel map function

Select how the 2:nd fuel map should be combined with the main fuel map.

- Use only 2 fuel maps, and add the two maps
- 2 extra fuel compensation maps
- Use only 2 fuel maps, and subtract the 2nd from the mail fuel map

2nd fuel map sensor

Select load sensor to use as base for the 2nd fuel map

3rd fuel map sensor

Select load sensor to use as base for the 3rd fuel map

Fuel injector dead time

The minimum electric pulse time the fuel injector needs to be able to open at all. Most injectors need minimum 1 millisecond to open. This setting affects all percentage



compensation maps and settings. The reason is that if you have 2ms fuel in the main map, the engine is only getting about 1ms fuel. If you then want to double the fuel, you should give 3ms which is 2ms fuel.

If the injector dead time is correct set, this is made automatically

Convert map to new axis

If you already have made a map, but want to change number of cells or desired range, it is possible to convert the current map to the new selection.

- 1) Save the current map by click at "Save current map". The current map is then saved in a new window.
- 2) Next step is to make all the changes you have in mind (Change size, rpm steps, load or sensors)
- 3) Finalize by "Convert saved map" and BCLab will automatically convert the old map to the new format as well as it is possible.

You must be observant and review the map one extra time just to make sure there where no unwanted effects in the conversion. If you have a map from 0-8000 rpm and reduce the range to 0-5000rpm, BCLab is capable to calculate the right value

BUT If you have a map from 0-5000 rpm and increase the range to 0-8000rpm, BCLab have to guess for the extra 3000 rpm, and the best guess is to use same values as for 5000 rpm column.

Table control

You are free to select RPM and load points for the fuel map. Select which cells to modify and press desired button.

Increase

Increases selected cell. All the cells below automatically changes as well.

Decrease

Decreases selected cell. All the cells below automatically changes as well.

Insert row

Inserts a new row to make more tuning points in a specific area. This removes the last cell.



Setting – Acceleration fuel enrichment

The system can add acceleration fuel enrichment, based on how fast you press the throttle. The system is measuring the throttle position 15 times/sec.

The acceleration fuel is controlled by three parameters.

Threshold

Threshold sets how much the throttle should be changed to activate the fuel enrichment. If this level is adjusted to 5V, you will never activate any acc fuel. If you set it to 0.02V, you will get acc fuel at slightest TPS change which will drown the engine.

Threshold fuel

Sets fuel pulse length when acceleration fuel is activated.

High load change

Sets a higher load point where you want to specify the acceleration fuel enrichment.

High load fuel

Sets fuel pulse length when high load change acceleration fuel is activated.

Low RPM

Sets a tuning point where you want to specify acceleration fuel.

Low RPM acceleration fuel %

Sets fuel pulse % at low RPM.

High RPM

Sets a high RPM tuning point where you want to specify acceleration fuel.

High RPM acceleration fuel %

Sets fuel pulse % at high RPM.

Sustain

Set how many acceleration fuel pulses the system should give after activation. The pulses is running with 40 pulses per second, so if you enter 20 pulses it will give acc fuel during 0.5 sec.

**View acceleration 3D graph**

Show a window with a 3D graph showing the resulting acceleration fuel, depending on RPM and thresholds.

Setting – Deceleration fuel

You can also remove fuel when throttle is closed rapidly.

Threshold

Threshold specify minimum change of TPS to start deceleration fuel

Fuel change gain

Set how much the fuel should be reduced. If you enter 1 ms/dV , the fuel pulses are shorten 1 ms if the TPS signal decrease with 1V at 1/20 sec.

Sustain

Sustain sets the number of engine cycles the deceleration fuel should be active



SETTING - IGNITION

Tuning settings

Ignition setup
 Crank ignition: 10,0 deg
 Ignition charge (dwell) time: 3,0 ms

Base ignition load on:
 3D Load sensor: MAP
 3D map size: 15 rpm x 13 analog (F)

Base 2nd and 3rd ignition load on:
 2nd Ignition Load sensor: AUX2/Air temp
 3rd Ignition Load sensor: Throttle

3D RPM and MAP Table set
 RPM resolution: 0 rpm
 MAP resolution: 0,00 bar
 Decrease value | Increase value | TPS

Convert map to new axis settings
 1) Save current ignition map
 2) Adjust the RPM and MAP resolution to match what you prefer
 3) Convert saved map

Also notice that the idle ignition is set under the Idle settings tab

Load	RPM
0,25	500
0,56	1000
0,87	1500
1,03	2000
1,19	2500
1,34	3000
1,5	3500
1,66	4000
1,82	4500
1,97	5000
2,13	5500
2,29	6000
2,44	6500
	7000
	7500

Launch / ALS | **Ignition settings** | PWM outputs | AFR control | Idle settings | Temp corrections | Start up
 Digital inputs | Analog settings | Limits / Warnings | Engine setup | Fuel acceleration | Fuel settings | Digital outputs | OK

Ignition setup

Crank ignition

Fixed ignition setting during cranking (engine start up)

Ignition charge (Dwell) time

Charge time for the coil before each spark

Ignition setup

3D ignition load sensor

Select load sensor for the ignition map [ignition map](#)

3D ignition map size

Selection of map size for the ignition map. There are 4 different sizes

- 18 rpm x 11 load *
- 15 rpm x 13 load *
- 11 rpm x 18 load
- 11 rpm x 11 load *

* this resolution is also selectable for fuel, so that you can get same resolution for both fuel and ignition.

2nd ignition load sensor

Select load sensor for the 2nd ignition map [ignition map](#)

3rd ignition load sensor

Select load sensor for the 3rd ignition map [ignition map](#)



Table control

You are free to select RPM and load points for the fuel map. Select which cells to modify and press desired button.

Increase

Increases selected cell. All the cells below automatically changes as well.

Decrease

Decreases selected cell. All the cells below automatically changes as well.

Insert row

Inserts a new row to make more tuning points in a specific area. This removes the last cell.

Convert map to new axis

If you already have made a map, but want to change number of cells or desired range, it is possible to convert the current map to the new selection.

- 1) Save the current map by click at "Save current map". The current map is then saved in a new window.
- 2) Next step is to make all the changes you have in mind (Change size, rpm steps, load or sensors)
- 3) Finalize by "Convert saved map" and BCLab will automatically convert the old map to the new format as well as it is possible.

You must be observant and review the map one extra time just to make sure there where no unwanted effects in the conversion. If you have a map from 0-8000 rpm and reduce the range to 0-5000rpm, BCLab is capable to calculate the right value

BUT If you have a map from 0-5000 rpm and increase the range to 0-8000rpm, BCLab have to guess for the extra 3000 rpm, and the best guess is to use same values as for 5000 rpm column.



SETTING - IDLE

Tuning settings

Idle activation

Throttle level to enter idle mode: 0.00 V

Idle RPM: 950 rpm

Idle ignition

☒ Off ☐ On

Idle ignition: 8.0 deg

Throttle level for idle ignition fade out: 0.57 V

Idle control settings

☒ Off ☐ On

Idle control type: ☒ Ignition

Idle control frequency: 6.7 Hz

Idle control, Gain (P): 2

Idle control, Sum (I): 1

Idle control, Difference (D): 20

When Throttle and RPM is below limit, the systems enter Idle mode. Idle mode activates Idle control, Idle lambda control. When Idle mode Launch control is deactivated.

You can select a separate idle ignition. When the throttle reach the specified idle ignition fade out limit, the ignition is fully based on the values in the main 3D map. I.e the idle ignition is fade out.

When using idle control, the ignition or idle valve at PWM2 can be used to control the idle RPM. If RPM is to low, the ignition is advanced, if too high the ignition is reduced. The maximum ignition is 25deg. The PID parameter controls how fast the closed loop should work. Also notice that the idle air is controlled from the PWM2 tab.

Launch / ALS Ignition settings PWM outputs AFR control **Idle settings** Temp corrections Start up

Digital inputs Analog settings Limits / Warnings Engine setup Fuel acceleration Fuel settings Digital outputs

OK

Idle activation

Throttle level to enter idle mode

Lowest throttle position level to activate special idle settings.

Idle RPM

Define which RPM that should be considered as desired idle RPM.

Used by idle control and AFR-control

Idle ignition

Idle ignition

Select if you want to use fixed idle ignition setting

Throttle level for idle ignition fade out

Sets at which throttle level the fixed idle ignition should be totally faded out. Normally set this a bit higher than "Throttle level to enter idle mode"

Idle control settings

Idle control frequency

Select the speed of the idle control

Idle control Gain, Sum and Difference

PID parameters to control the speed and behavior of the ignition idle control.



SETTING – AFR CONTROL

AFR settings

AFR sensor type

Set wide band or narrow band type

AFR sensor low voltage

Sets if the narrow band sensor gives low voltage at rich or lean AFR

AFR start delay

Sets the AFR start up delay until the AFR control should be activated after start up. This is to make sure the AFR sensor is heated.

AFR control, Sum parameter

Sets the AFR control speed at idle. Too fast control can result in an oscillating idle.

AFR min load to be active

Sets the minimum load to still use AFR-control. This is made to prevent AFR control during engine brake.

AFR max load to be active

Sets the maximum load to still use AFR-control. This is made to prevent AFR control at full load.

AFR max RPM to be active

Sets the maximum RPM to still use AFR-control. This is made to prevent AFR control at high rpm.

Load level to start AFR supervising

Specify at which load the system should start supervising the AFR and set error codes.

Typically you want to get warning if the AFR is to lead at boost..



AFR min load sensor

Sets if you want AFR-control to be deactivated depending on low load or when RPM and Throttle is low.

AFR max load sensor

Sets which load sensor that should be used as max load sensor for AFR-control (normally throttle or MAP).

Narrow band sensor

If narrow band sensor is used and no real AFR value is read you set which voltage that is considered as AFR=14.7 (Lambda=1). Normally a narrow band sensor toggles between 0V and 1V, and a suitable value could then be 0.5V.

Wide band sensor

If a wide band sensor is used, you can set which AFR-value you desire for each load in a normal table in the main program [AFR-table](#).

SETTING – AFR CONTROL AUTO TUNE

Normally the AFR-control is of the type "short term adaptive", ie the AFR-signal is tested several times per second and immediately the fuel is corrected .

With Auto tune the system can rewrite the fuel map continuously, which makes the fuel map better and better the longer the engine is running.

You can select if the Auto tune should be on/off or be controlled by Digital 1 in. Civinco recommends that you actively selects if the Auto tune should be on or off so you know when it is happening.


WARNING!

Auto tune is a slow long term tuning, and will not replace the need for a good fuel map to start with. It will not help replace the need for manually tune the full load etc, but on the other hand is this the easy part of tuning.

It also demands that the AFR signal is correct, or otherwise the fuel map will be rewritten by mistake.



SETTING – TEMPERATURE COMPENSATION



Coolant temperature fuel correction

Choke fuel

Set percentage of extra fuel depending on low temperature. The system is linear and adds less and less fuel until the engine is considered warm.

Crank snaps fuel

Sets one fixed long fuel pulse which occurs as soon as the engine starts to turn around when it is cold (at start up). The system is linear and adds less and less fuel until the engine is considered warm. This is particularly good to use when running on ethanol (E85).

Cold engine temperature

Set which temperature that should be considered as cold limit.

Warm engine temperature

Set which temperature that should be considered as normal engine temperature.

The AFR control will not start until the engine has reached this temperature.

Coolant temperature to start fan

Set at which temperature the electric fan should start at. When the fan has been started, it turns off when the temperature has reached about 5 deg below this temperature

Air temperature fuel correction

Sets how much the intake air temperature should compensate the total fuel with. The system is linear between the cold and the warm temperature limit. Normally IAT that is 30 deg Celsius colder, needs 10% more fuel.

Low air temp fuel

Sets the extra fuel percentage below the “Low air temp limit”.

Low air temp limit

Sets the temperature that should be considered as cold temperature.

High air temp fuel


Sets the extra fuel percentage above the “High air temp limit”

High air temp limit

Sets the temperature that should be considered as warm temperature.



SETTING – BATTERY VOLTAGE AND START UP COMPENSATION



Low battery correction

Sets how much the fuel injector pulses should be extended at low battery voltage. At engine start the battery voltage normally drops, which slows down the performance of the fuel injectors.

Start up fuel

Sets extra fuel that will be added to the main fuel at start and a specified time after start up. Most engines need some extra fuel a few seconds after start.

Start up idle air

Sets extra air that will be added at start and a specified time after start up. This demands that the idle air control is set to PWM2.



SETTING – LIMITS AND WARNINGS

Tuning settings

Rev Limit
 Fuel and Ign cut RPM: 6300 rpm
 soft fuel cut 250rpm earlier: 5200 rpm
 2nd RPM limit controlled by Coolant

Boost limit
 Fuel cut boost level: 2,11 bar

RPM indicator LED
 RPM Indicator (Led 2): 5700 rpm

Error codes

Error code	Error lamp	Counter M	S
Crank error	<input checked="" type="checkbox"/>	0	0
Sync error (cam/crank)	<input type="checkbox"/>	0	0
Rev Limit	<input type="checkbox"/>	0	0
Boost limit	<input type="checkbox"/>	0	0
AFR Short adaptive low	<input type="checkbox"/>	0	0
AFR Short adaptive high	<input type="checkbox"/>	0	0

Clear all error code counters

Analog warning levels and Error codes

Parameter	Value	Unit	Error code	Error lamp	Counter M	S
AFR low	0,00	V	<input type="checkbox"/>	<input type="checkbox"/>	0	0
AFR high	5,00	V	<input type="checkbox"/>	<input type="checkbox"/>	0	0
Throttle low	0,00	V	<input type="checkbox"/>	<input type="checkbox"/>	0	0
Throttle high	5,00	V	<input type="checkbox"/>	<input type="checkbox"/>	0	0
MAP low	0,09	bar	<input type="checkbox"/>	<input type="checkbox"/>	0	0
MAP high	2,59	bar	<input type="checkbox"/>	<input type="checkbox"/>	0	0
Coolant high	160,00	C	<input type="checkbox"/>	<input type="checkbox"/>	0	0
Coolant low	-35,00	C	<input type="checkbox"/>	<input type="checkbox"/>	0	0
12V/Aux1 low	0,00	V	<input type="checkbox"/>	<input type="checkbox"/>	0	0
12V/Aux1 high	22,32	V	<input type="checkbox"/>	<input type="checkbox"/>	0	0
IAT/Aux2 high	190,00	C	<input type="checkbox"/>	<input type="checkbox"/>	0	0
IAT/Aux2 low	-47,80	C	<input type="checkbox"/>	<input type="checkbox"/>	0	0
12V/Aux3 low	0,00	V	<input type="checkbox"/>	<input type="checkbox"/>	0	0
12V/Aux3 high	22,32	V	<input type="checkbox"/>	<input type="checkbox"/>	0	0
IAT/Aux4 high	190,00	C	<input type="checkbox"/>	<input type="checkbox"/>	0	0
IAT/Aux4 low	-47,80	C	<input type="checkbox"/>	<input type="checkbox"/>	0	0
Max AFR at AFR supervising	2,10	V	<input type="checkbox"/>	<input type="checkbox"/>	0	0
Load level to start AFR supervising	2,59	bar	<input type="checkbox"/>	<input type="checkbox"/>	0	0

Error code will be set if analog input voltage is below low limit or above high level.
 Notice that normally temperature sensors sends low voltage at high temperature

Navigation: Digital inputs, Analog settings, **Limits / Warnings**, Engine setup, Fuel acceleration, Fuel settings, Digital outputs, Launch / ALS, Ignition settings, PWM outputs, AFR control, Idle settings, Temp corrections, Start up, OK

Fuel and Ignition cut Rev limit

Sets a specific RPM where fuel and ignition should be cut off (the Rev limit)

150 RPM before the main Rev limit, there is a soft RPM limit which cut the ignition on every second cylinder.

2nd Fuel and Ignition cut Rev limit

Sets a 2nd RPM where fuel and ignition should be cut off (the Rev limit) Normally the 2nd Rev limit is controlled by the coolant temperature. When the coolant gets warmer, the 2nd RPM limit is increased up to 1st Rev limit when the engine is warm.

Paddock speed limit

2nd RPM limit can also be controlled by Digital 1 or Digital 2 in, which will result in a paddock speed limiter if properly configured.

Boost limit

Sets at which boost (MAP), the fuel should be cut off.

RPM indication

At the front side of the system there is one LED that can be turned on at this specific RPM. If one of the digital outputs is set to be used as gearing indicator this output will also be set.

Warning levels and error codes

Sets valid range for the analog inputs, and if the Error code output should be set if the signal is outside the valid range.

Counters

Every time an error occurs in the system the error counter is increased. Errors are tracked both on master and slave board. By pressing clear error codes, the counters are cleared. (Make sure also to write settings to box)



SETTING – PWM AND BOOST CONTROL

PWM 1 Settings, (Master pin 5)
Tune PWM 1 based on: Coolant temp, Mas
PWM1 compensation based on: Throttle, Master

PWM 1 closed loop boost control
☒ Activate Boost control PID closed loop.
P (Proportional): 21, I (Sum): 20, D (Difference): 21, Init value %: 100

PWM 2 Settings, (Master pin 9)
Tune PWM 2 based on: Coolant temp, Mas
PWM 2 frequency: 38Hz, 150 Hz
PWM 2 polarity: Normal, Inverted (0%=100%)

PWM 2 External activation
PWM external activation controlled by Fan
PWM change on activation: 7.0 %

PWM 3 Settings, (Slave pin 5)
Tune PWM 3 based on: AFR, Slave

PWM 4 Settings, (Slave pin 9)
Tune PWM 4 based on: AFR, Slave
PWM 4 frequency: 38Hz, 150 Hz

PWM 2 idle air fuel map
Fuel correction based on PwM2: Off, On
Adjust PWM value by selecting row and pressing buttons. Adjust extra fuel by entering desired value.

	PWM %	Fuel ms	
Increase PWM	0,0	0,0	Increase Fuel
	0,4	0,0	
Decrease PWM	0,8	0,0	Decrease Fuel
	1,2	0,0	
	1,6	0,0	

Launch / ALS, Ignition settings, **PWM outputs**, AFR control, Idle settings, Temp corrections, Start up, Digital inputs, Analog settings, Limits / Warnings, Engine setup, Fuel acceleration, Fuel settings, Digital outputs, OK

The BC-system has 2 (SA500G3) respective 4 (SA1000G3) PWM-outputs which can be tuned depending on load or RPM.

Tune PWM based on

Each of the four PWM outputs can set to use RPM or any load as base for the tuning

PWM1

PWM1 also supports closed loop boost control with PID. The basic principle is that the current boost is measured all the time and depending on desired boost, the control signal to the boost control valve is regulated.

At each sample you measure the current boost and compare to the desired boost. The difference is called the “error”.

The P-factor controls how much the control signal should increase depending of the error. (Proportional factor).

The I-factor controls how the control signal should increase if the error stays over time. After each measurement the control signal is increase a little more if the error stays.

The D-factor controls how much the control signal should change if an sudden error occurs. This is to take care of sudden changes like boost drop.

$$\text{Out signal} = \text{Error} * P + \text{Long time error} * I + \text{Sudden signal change} * D$$



If you need more information regarding PID, Civinco has a separate documentation of this.

Boost sensor

Selects which sensor that is used as boost sensor. Only used for PID.

PWM2

PWM2 and PWM4 also supports two different PWM frequencies 38Hz and 150Hz. The higher speed is used by idle engines.

PWM external activation

PWM2 can be externally activated by electric fan control or one of the digital inputs. This is good if you want to increase the PWM to the idle engine when electric fan is turned on.

Fuel correction based on PWM


If you run a throttle based map, and idle control you must add extra fuel when increasing the idle engine control. In this table you tune the idle fuel.

PWM 3-4

Straight forward PWM outputs.



SETTING – DIGITAL 1&2 IN



Setting – Digital 1 in

Not activated

Digital 1 is not used. You can still log the signal.

Launch control

Digital 1 is used to control Launch control activation.

2nd RPM limit activated

Digital 1 is used to control RPM limit 2. If this is not selected the 2nd RPM limit will be controlled by coolant temperature.

Inställning – Digital 2 in

Not activated

Digital 2 is not used. You can still log the signal.

Fuel long term adaptive

Control the Auto tune via digital 2 in. Demands that the AFR control tab also is set to digital 2 in.

Ignition cut

Control the ignition cut at gearing with digital 2 input. When activated the ignition is cut during selected milliseconds.

External activation of PWM idle air

Digital 2 can also control if the idle air should be increased. If you connect to the signal from the A/C, you could increase the idle air to get stable idle. This also demands that the PWM tab is set to the same setting.

ALS

Digital 2 is used to control ALS

2nd RPM limit activated

Digital 2 is used to control RPM limit 2. If this is not selected the 2nd RPM limit will be controlled by coolant temperature.



INSTÄLLNING – LAUNCH CONTROL & ALS

WARNING. By using the launch control or ALS heating up the exhaust system and valves much more than a stock engine can handle. These functions should only be used on race cars which is designed to handle this heat.

The screenshot shows the 'Tuning settings' window with the 'Launch and antilag (ALS) settings' tab selected. The settings are as follows:

- Launch ignition retard: 60.2 deg
- Launch extra fuel: 80.1 %
- Launch RPM start: 3500 rpm
- Launch RPM limit: 5500 rpm
- ALS ignition retard: 60.2 deg
- ALS extra fuel: 80.1 %
- ALS min TPS: 1.00 V
- ALS max TPS: 4.00 V
- ALS minimum RPM: 3000 rpm
- ALS max PWM2 output: 99.6 %
- Anti lag activates PWM2, to give the extra air (idle valve): ☒
- Launch/ALS high temp sensor: Coolant temp
- High temp=high voltage: ☐ High temp=low voltage: ☒
- Launch/ALS high temp cut off: 160.00 C

At the bottom, there are tabs for: Launch / ALS, Ignition settings, PWM outputs, AFR control, Idle settings, Temp corrections, Start up, Digital inputs, Analog settings, Limits / Warnings, Engine setup, Fuel acceleration, Fuel settings, and Digital outputs. An 'OK' button is at the bottom right.

Inställning – Launch control

Launch control is a function to spool up the turbo at start line. This is done by activating launch control by grounding the launch control signal input, and press the throttle. The engine will the rev up to the set rev limit and at the same time retard the ignition and give extra fuel. The result is that the fuel is burned in the exhaust, which spins up the turbo. It is very dangerous to use this function any long time (more than a few seconds), because the exhaust gets very hot.

Launch ignition retard

Selects how much to retard the ignition when launch control is activated.

Launch extra fuel

Sets how much extra fuel to add when launch control is activated.

Launch RPM limit

Sets a temporary rev limit when launch control is activated.

Launch RPM start

The RPM where the extra fuel and ignition retardation should start to add. The fuel and ignition retard is then increased up to maximum at Launch RPM limit

Launch control settings example

Launch	
Ignition retard	60,0 deg
Extra fuel	80,0%
RPM Start	3500
RPM Limit	5500

RPM	0	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000
Tändsänkning	0	0	0	0	0	0	0	0	-15,0	-30,0	-45,0	-60,0	-60,0	-60,0	-60,0
Extrabränsle	0%	0%	0%	0%	0%	0%	0%	0%	20%	40%	60%	80%	80%	80%	80%



Settings – ALS

Anti lag system (ALS) is a function to keep the boost even at part load and at engine brake.

When the ALS is active, the following happens:

1. the ignition is retarded,
 2. extra fuel is given,
 3. extra air is given (through idle valve or via separate air valve to the exhaust)
- More and more of the combustion is taking action in the exhaust system, which generates exhausts without the engine is reaching RPM limit. This keeps the turbo spinning

ALS example

ALS	
Ignition retard at 100% ALS	60,0 deg
Extra fuel at 100% ALS	80,0%
min TPS*	1,0
max TPS**	3,5
min RPM***	3000
max PWM2 out	100%
PWM2 in PWM table	
(normally varies with temp.)	
	80%

ALS min TPS

TPS value at released TPS, which also is the value where the ALS will be maximum activated.

ALS max TPS

TPS value where you want the ALS to be fully deactivated. Normally somewhere between part load and full load.

ALS min RPM

Lowest RPM where you want ALS to be activated. This is to prevent ALS to be active at idle and low speed driving. The ALS is activated at this RPM and is successively activated more and more until RPM is 1000 above this level

ALS ignition retard

How much the ignition should be retarded at fully released throttle. The more you press the throttle (up to max TPS), the more the ignition is retarded.



ALS ignition example, based on settings above

ALS Ignition retard															
	RPM														
TPS	0	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000
0,0	0	0	0	0	0	0	0	-30	-60	-60	-60	-60	-60	-60	-60
0,5	0	0	0	0	0	0	0	-30	-60	-60	-60	-60	-60	-60	-60
1,0	0	0	0	0	0	0	0	-30	-60	-60	-60	-60	-60	-60	-60
1,5	0	0	0	0	0	0	0	-24	-48	-48	-48	-48	-48	-48	-48
2,0	0	0	0	0	0	0	0	-18	-36	-36	-36	-36	-36	-36	-36
2,5	0	0	0	0	0	0	0	-12	-24	-24	-24	-24	-24	-24	-24
3,0	0	0	0	0	0	0	0	-6	-12	-12	-12	-12	-12	-12	-12
3,5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
4,0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
4,5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
5,0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

ALS extra fuel

The amount of extra fuel which will be added at fully released throttle.

ALS extra fuel example, based on settings above

ALS extra fuel															
	RPM														
TPS	0	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000
0,0	0%	0%	0%	0%	0%	0%	0%	40%	80%	80%	80%	80%	80%	80%	80%
0,5	0%	0%	0%	0%	0%	0%	0%	40%	80%	80%	80%	80%	80%	80%	80%
1,0	0%	0%	0%	0%	0%	0%	0%	40%	80%	80%	80%	80%	80%	80%	80%
1,5	0%	0%	0%	0%	0%	0%	0%	32%	64%	64%	64%	64%	64%	64%	64%
2,0	0%	0%	0%	0%	0%	0%	0%	24%	48%	48%	48%	48%	48%	48%	48%
2,5	0%	0%	0%	0%	0%	0%	0%	16%	32%	32%	32%	32%	32%	32%	32%
3,0	0%	0%	0%	0%	0%	0%	0%	8%	16%	16%	16%	16%	16%	16%	16%
3,5	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%
4,0	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%
4,5	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%
5,0	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%

ALS max PWM

The level of PWM that should be given at fully released throttle. This demands that the systems controls the idle air valve by PWM2, or some other air valve.

Note that if you control the idle by PWM2, most likely you already have a value for the PWM in the PWM2 table

ALS PWM example

ALS PWM																
	RPM															
TPS	0	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	
0,0	80%	80%	80%	80%	80%	80%	80%	50%	100%	100%	100%	100%	100%	100%	100%	
0,5	80%	80%	80%	80%	80%	80%	80%	50%	100%	100%	100%	100%	100%	100%	100%	
1,0	80%	80%	80%	80%	80%	80%	80%	50%	100%	100%	100%	100%	100%	100%	100%	
1,5	80%	80%	80%	80%	80%	80%	80%	48%	96%	96%	96%	96%	96%	96%	96%	
2,0	80%	80%	80%	80%	80%	80%	80%	46%	92%	92%	92%	92%	92%	92%	92%	
2,5	80%	80%	80%	80%	80%	80%	80%	44%	88%	88%	88%	88%	88%	88%	88%	
3,0	80%	80%	80%	80%	80%	80%	80%	42%	84%	84%	84%	84%	84%	84%	84%	
3,5	80%	80%	80%	80%	80%	80%	80%	40%	80%	80%	80%	80%	80%	80%	80%	
4,0	80%	80%	80%	80%	80%	80%	80%	80%	80%	80%	80%	80%	80%	80%	80%	
4,5	80%	80%	80%	80%	80%	80%	80%	80%	80%	80%	80%	80%	80%	80%	80%	
5,0	80%	80%	80%	80%	80%	80%	80%	80%	80%	80%	80%	80%	80%	80%	80%	




ALS max temp sensor

Both launch control and ALS can be forced to stop if a temperature signal is too high. The most common is to use coolant or exhaust gas temperature as limit.

The coolant sensor is most common to have a signal that where the voltage goes down when the temperature is too high, and the EGT sensor is vice versa. Because of this it is selectable to control the function both ways.

SETTING – ANALOG



Analog input synchronization

There can occur pulse phenomenon at some signals (mostly MAP-signal) during the engine cycle. To avoid strange values of the MAP it is possible to synchronize the measurement with the engine rev (instead of always use fixed sample rate 600 Hz).

Internal MAP sensor range

If you have an internal 4 bars map-sensor you can select to use it as a 2 bar sensor (high resolution) or in normal mode 4 bar, which is also the default



SETTING – DIGITAL OUTPUT

Tuning settings

Digital out1 Settings, (Master pin 3)
 Digital out 1 function: ASD
 Digital out 1, sensor input: AFR, Master
 RPM ON: 0
 RPM OFF: 0
 Analog ON: 0.61 lam
 Analog OFF: 0.61 lam

Digital out2 Settings, (Master pin 7)
 Digital out 2 function: Vanos/VTEC
 Digital out 2, sensor input: MAP, Master
 RPM ON: 3438
 RPM OFF: 6938
 Analog ON: 0.77 bar
 Analog OFF: 1.98 bar

Digital out3 Settings, (Slaver pin 3)
 Digital out 3 function: RPM tach
 Digital out 3, sensor input: AFR, Slave
 RPM ON: 0
 RPM OFF: 0
 Analog ON: 0.61 lam
 Analog OFF: 0.61 lam

Digital out4 Settings, (Slave pin 7)
 Digital out 4 function: RPM controlled
 Digital out 4, sensor input: AFR, Slave
 RPM ON: 5500
 RPM OFF: 15938
 Analog ON: 0.61 lam
 Analog OFF: 1.29 lam

Sensor

RPM

Launch control | Analog settings | Limits and Warnings | Engine setup | Fuel settings | **Digital outputs**
 Ignition settings | PWM outputs | AFR control | Idle settings | Temp corrections | Start up fuel | OK

There is 4 digital output that can be individually controlled by RPM and load

Following functions are supported:


- ASD/DME-relay To control the fuel pump, ignition system etc.
On as long as the engine is revving
- RPM tach Output signals for tachometer.
 - Sends same number of pulses as number of cylinders
- Fan control Signal to control fan relay.
 - On temperature is set under temperature settings
- Error code Set when an error code is set. Could control an error code lamp
- RPM controlled
 - RPM On RPM when the output is activated
 - RPM Off RPM when the output is deactivated
- Analog controlled
 - Analog On The level of the analogue signal that should activate the output
 - Analog Off The level of the analogue signal that should deactivate the output
- VANOS/Vtec Controlled by both RPM and analogue signal.
 - RPM On
 - RPM Off
 - Analog On
 - Analog Off

The green box represents the working area where the output is activated (grounded). If you want to control a relay or lamp etc. you should supply the relay with +12V.





LOGGING



In BCLab you can log all engine signals that is connected to the system in real time with 20 samples per second. BCLab can also calculate and present a number of extra signals like:

- Power and torque
- Speed and acceleration
- Duty Cycle on output fuel
- Fuel consumption

BCLab presents all the logged data in a graph, which also can be saved to a file for later use.


LOG MENU

File open

Opens a stored file.

Open and compare

If you already have an open file, and want to compare it with another file. Perfect if you want to compare to different power log files.



You can also open a file in compare mode by first click at it as normal, and then right click at it

If you have 2 files open at the same time you will also get 2 extra cotrols so that you can adjust it against each other. By left click you make large steps, and right click makes small adjustments.

Select log file to open

Double click at a file in the window to open it. If you only click on the file, you will see a preview without open it to enable easy browsing the files.

File information

At logging the date and time will automatically set. In the free text window it is possible to write your own comments.

Logging

Starts, stops and clear the logging. Make sure the system is connected first via an USB cable

Seconds to show while logging

Here you set how many seconds of the log that should be visible during logging (running window). If you have a slow computer you should decrease the number of seconds. Normally 5-10 seconds.

Update interval

Here you set how often the window should be updated during logging. Normally 0.1-1 seconds.

Chart scale options

Here you set the maximal and the minimal value on respective y-axle. If it says “Auto” it is automatically adjusted for best view.



Select signals to view

Here you select which signals to view. You can also select if the signal should be visible on the left or right y-axle. This is good if you look at signals with a big difference in value (example RPM and Volt). Normally the RPM is showed on the 2nd axle and all the other signals on the 1st axle.

Chart controls

Scroll left

Moves the graph to see earlier values

Scroll right

Moves the graph to see later values

Zoom in

Zoom in the graph 2 times.

Zoom out

Zoom out the graph 2 times.

Zoom all

Zoom out so that all values are visible.

Redraw

Redraw the graph.

Export these settings to box


All engine settings are automatically saved together with the log data. If you open an old log file, you can click on this button to transfer the settings from the log file to the main program. This makes it possible to restore the settings you had when you made the current log.

Also see chapter [BC Log settings](#) for all log settings.




Live Data changes during logging

If you do changes in the mapping or settings during logging, these changes will take part immediately. You do not have to press “Write” for the changes. This makes it easier to make changes in the mapping and immediately see the changes in the log file. I.e if you make fuel adjustment, you can see the AFR change right away.



The log data is also shown in the tuning program as a red cursor in current load/RPM cell.


Show RPM graph



In the RPM-graph all the log data is showed with rpm instead of time on the x-axle. This is good for analyzing data that depends on RPM like power, torque, AFR etc.



LOGGING WITH EXTERNAL DISPLAY



If you only want to view some parameters from the log window you can open a separate window that shows the same parameters as in the log window but as bars and numbers. Short command to open the display is Shift + F8

LOG SETTINGS

The Log settings window displays a list of signals and their corresponding sensors. The window is titled "CIVINCO SA500/SA1000 Interface Software - Log settings". It contains two main columns for signal selection, each with a "Custom Name" and "Sensor" dropdown menu. The signals are numbered from 0 to 73. The sensors are listed in the right column. The window also includes buttons for "Car Settings", "Import default log sensors", "Save as Default", "Cancel", and "OK".

Signal	Custom Name	Sensor	Signal	Custom Name	Sensor
0: RPM	RPM	RPM_S	40: POWER	Power	Power
1: IGN	IGN	Ignition 0-51	41: TORQUE	Torque	Torque
2: FUM	Fuel_M	Fuel	42: SPEED	Speed	Speed
3: FUT	Fuel-tab	Fuel	43: ACC	ACCELERATION	Accel
4: FTM	Fuel-trim_M	Fuel-trim_%	44: FUEL	TOT Fuel DC	Fuel_DC
5: FWT	ChokeFuel-add	TempFuel-add_%	45: NIY_	Analog_0-5V	Analog_0-5V
6: FAT	AirTempFuel-comp	TempFuel-add_%	46: NIY_	Analog_0-5V	Analog_0-5V
7: FVA	VoltageFuel-add	Fuel++	47: AD1_Bin	AD_0-255	AD_0-255
8: FAE	FuelAccEnrich	AD_0-255	48: AD2_Bin	AD_0-255	AD_0-255
9: PW1	PWM1 Out	PWM_Out_0-100%	49: AD3_Bin	AD_0-255	AD_0-255
10: PW2	PWM2 Out	PWM_Out_0-100%	50: BoostLimit	Status1	Status1
11: O2M	AFR_M	TE_WB_AFR	51: RevLimit	Status1	Status1
12: THM	Throttle_M	Analog_0-5V	52: GearCut	Status1	Status1
13: MPM	MAP_M	MPX 2.5bar	53: Launch	Status1	Status1
14: WTM	CoolantTemp_M	P928_WaterTemp	54: Fan	Status1	Status1
15: VDM	Battery_M	Battery	55: LambdaControl	Status1	Status1
16: ATM	AirTemp_M	SAAB_AirTemp	56: Idle	Status1	Status1
17: ST1	Statusbyte1	Status1	57: Cranking	Status1	Status1
18: ST2	Statusbyte2	Status2	58: Cam/Crank miss	Status2	Status2
19: ST3	Statusbyte3	Status3	59: RPM Indicator	Status2	Status2
20: FUS	Fuel_S	Fuel	60: Dig1 Indicator	Status2	Status2
21: FTS	Fuel-trim_S	Fuel-trim_%	61: Dig2 Indicator	Status2	Status2
22: PW3	PWM3 Out	PWM_Out_0-100%	62: Dig3 Indicator	Status2	Status2
23: PW4	PWM4 Out	PWM_Out_0-100%	63: Dig4 Indicator	Status2	Status2
24: O2S	AFR_S	TE_WB_AFR	64: Stat2_6 Indicator	Status2	Status2
25: THS	Throttle_S	Analog_0-5V	65: Err Code	Status2	Status2
26: MPS	MAP_S	MPX 2.5bar	66: Stat3_0 Indicator	Status3	Status3
27: WTS	CoolantTemp_S	P928_WaterTemp	67: Stat3_1 Indicator	Status3	Status3
28: VDS	Battery_S	Battery	68: Stat3_2 Indicator	Status3	Status3
29: ATS	AirTemp_S	SAAB_AirTemp	69: Stat3_3 Indicator	Status3	Status3
30: NIY_SPEED1_M	Speed	Speed	70: Stat3_4 Indicator	Status3	Status3
31: NIY_SPEED2_M	Speed	Speed	71: Stat3_5 Indicator	Status3	Status3
32: NIY_FAdap_M	Fuel++	Fuel++	72: Stat3_6 Indicator	Status3	Status3
33: NIY_IGNCharge	Status3	Status3	73: Stat3_7 Indicator	Status3	Status3
34: NIY_SPEED3_S	Speed	Speed			
35: NIY_SPEED4_S	Speed	Speed			
36: NIY_FAdap_S	Fuel++	Fuel++			
37: NIY_	Fuel++	Fuel++			
38: NIY_	Fuel++	Fuel++			
39: NIY_	Fuel++	Fuel++			



Signal name and selection of log sensor

BCLab can log up to 75 signals. All the signals have got a default name, which can be changed by the user to simplify the reading depending on your specific situation. For each signal you can also select different sensor definitions depending on if you like to analyze the signals in Volt or AFR etc.

Also have a look at chapter [Sensor specifications](#) for more information about sensors.

Log file settings

Default log file name

The name you want to show as default.

Auto save

If you like the files to automatically be saved when stop logging. The log file will automatically be named with default name and time.

Fuel injectors

Specify the size of the fuel injectors for the fuel calculations.



Other settings

Import default log sensors

If you open an old log file, you can import newest sensor definitions from the default file to the old log file.

POWER CALCULATION

The power calculation is based on the acceleration of the car at full throttle. To make sure the power calculation is as correct as possible you must make sure you know the weight of the car, is running on absolutely flat road and also know the air resistance and the power train losses. If you make two runs without changing these parameters you can be sure that you can compare the runs with high accuracy. .

First of all you need to set the right gearing ratio. Normally it is suitable to make full throttle pulls at 3rd gear. Easiest to find the gearing is to make sure how fast you run at a certain RPM at a certain gear, and use the calculator. The best way is to use a GPS to detect true speed, but speed meter is almost as good. Just make sure you do not change tire to different size.

Next the weight is very important, just as the car was at the run. Either you weigh the car, or make estimation. The power is proportional to the weight, so if you enter half the weight the power also is halved

It is also important to add losses for the air resistance. If you want to see exactly how much the air resistance adds, enter car weight 0lbs and transmission losses to 0. Typically the air resistance is 12hp at 60 mph and 100 hp at 120 mph

Finally you need to estimate the power train losses if you want to know the power at the crankshaft. Typically this is 15-25%.

If you want to compare the numbers with Dyno numbers or car manufactures, it is good to know that the power numbers is given from a specific standard. For instance normally the power is given at a specific temperature (70F) An engine produces more power if it is cold, so the standard compensates for this and lower the numbers if it is cold during the run.

Car weight

Specify the weight of the car. This is used for power calculations.

Gearing calculator

You can write the cars gear ratio directly in the box "Gearing". If you don't have access to this the program can calculate it for you. Specify rpm, speed and gear and click "Calculate gearing" and the program calculates your gear ratio on that gear. This matters when you calculate engine power and speed. The graph values are only correct for the calculated gear. You can choose which gear you want the program to use during engine power calculation in the log window.



Power settings

Min/max values

Here you can filter how large and how small values you want to see in the graph to hide wrong values during gearing etc.

Air resistance

If you know the air resistance of the car, the C_w number, and the frontal area of the car, you can compensate for it in the power calculation. The resulting power will then be true wheel horse power. The C_w and frontal area numbers you can sometimes find in the technical manual of the car. Typically the C_w varies from 0.3 to 0.35. A medium sized car has frontal area of about 2 m^2 .

Power train losses

If you know the transmission losses or want to make an estimation to have the power on the crankshaft this is possible. You enter the estimated loss in % at 1000 rpm and 6000 rpm. If you think you have 20% for all rpm, you enter this in both boxes.

MAIN MENU FOR LOGGING - FILE

Open

Open an old log file, called .cbl files

Save


Save current log file.

Save As

Save current log file with new name.

Export log data

Save the log data as a image or as an text file which can be opened in Excel.




Current log exported as image

	A	B	C	D	E	F
	TIME	RPM	AN1	AN2	AN3	F
1	20,95	7689,98	4,02344	3,65234	0	
2	21	7689,79	4,02344	3,65234	0	
3	21,05	7689,61	4,02344	3,65234	0	
4	21,1	7689,43	4,02344	3,65234	0	
5	21,15	7689,24	4,02344	3,65234	0	
6	21,2	7689,06	4,02344	3,65234	0	
7	21,25	7688,88	4,02344	3,65234	0	
8	21,3	7688,69	4,02344	3,65234	0	
9	21,35	7688,51	4,02344	3,65234	0	
10	21,4	7688,33	4,02344	3,65234	0,019531	

current log exported to Excel



OSCILLOSCOPE LOGGING



This is a high speed log mode for logging of the digital inputs with 10'000 samples per second. This makes it possible to log cam and crank to find timing or errors.



MAIN MENU

MENU – FILE

Open

Open Tune card files with car settings, named .cbc files.

Save

Save current settings to a TuneCard-file.

Save As

Save current settings to a TuneCard-file, with a new name

Exit

Quit BCLab

MENU – EDIT


Undo

Regret latest change.

Redo

Redoes the latest "Undo"

MENU – COMMUNICATION



For more details see page [General/Chipdrive status](#)

Toggle between Card and Direct communication (Ctrl+R)

Change between communication with the BC-system and the Tune Card writer. Same as click on the tab "BC-box" or "TuneCard"

Toggle between Card writers (Ctrl+T)

Toggle between different tune card writer types. Currently Chipdrive and Todos are supported.

Start Logging

Start logging without first opening the log window.



MENU – VIEW

3D-view

Opens a separate window and shows the 3D view for the ignition map, 2nd fuel map and the PWM map. Also have a look at [3D-view](#).

Log window


Opens the log window. See also [Logging](#).

Oscilloscope

Opens high speed logging. See [Oscilloscope logging](#).

MENU – SETTINGS

PC settings



Com-port (Virtual USB Com port)

Here you select to which com port the system is connected. When installing the USD driver which is provided with the system, each USB connector on your PC will get a dedicated com port number.

Interface


Here you select how you like to communicate with your tune cards. See also [The tab General/Chipdrive status](#)

Log settings

Open the log settings window. See also [log settings](#).



MENU-SENSOR SETTINGS



You can connect many different analog sensors to the BC-system. Most likely the stock sensors of the car, but also AFR, MAP etc. All the sensors sends an analog signal that varies between 0 and 5 Volt. The sensor definitions is a translation between Volt and the unit you prefer to view the signals in (bar, inches of vacuum, AFR, Fahrenheit etc.)

In the BCLab there is two sensor setups which are separated. One for the tuning part of the program, and one for the logging part of the program. The sensor definitions can be totally independently set up. These setups handle the tuning part.


Used Analog Sensor

Specify what kind of sensor you like for each analog input.

The sensors used for logging is adjusted in [log settings](#)



MENU - SENSOR VIEWER



Here you can have a look at a specific sensor..

There are 3 different types of sensors.

Linear, - Saved as a straight line.

Linear with special negative values – Saved as a line, but made to represent negative values which is sent from the BC-system to the PC.

Table sensors. – Saved as a 33 rows table with 0.16V per step, where you for each voltage can specify the sensor data. This is typically used for unlinear temperature sensors.

These tuning sensors are stored in the setup file with ending .ini in the program folder.

Open sensor definition

Open an already saved tuning or log sensor.

Save as new sensor

If you have edited an existing sensor or created a new one, you can save it by this control.

Enter desired name. If you use a name which already exists, it will replace the existing.

Select which type of sensor you have created, and select the right alternative.

Finally choose if you want to save as tuning sensor, log sensor or both.

The sensor definitions used for tuning are stored in the folder where you installed the program in the SA500_1000.ini file.

Sensors used for the log part of the program are stored in each log file (xxx.cbl) which are located where you selected to store them.



The log sensor definitions that are used as default when you start the program are stored in the file Default_Log_Settings.cbl file that is located in the same folder as the program installation.

Sensor tester

A calculator which is used for testing your sensor definitions. You can use it both for forward and backward calculation.

Linear control

If you have created a linear sensor or a 2c sensor, you create the definition by specifying two points at the line.


Table control

If you have created a tab sensor, you are free to change all values in the table with help of this tool. You can also enter the values directly into the table.

TPS Calibration

Creates a calibrated TPS sensor definition which is automatically set to be 0% at released throttle and 100% at full throttle. To be able to do this, you must have a system which is connected to the car.

1. Press TPS Calibration
2. Release the throttle and press OK
3. Press the throttle fully and press OK
4. Now the sensor is automatically created and you can select to store it as tuning sensor or log sensor or both.
5. When you have made a recalibration, you must make sure that you also change the corresponding maps where you use TPS as load sensor.



MENU – HELP

Go to Civinco

Opens the Civinco home page www.civinco.com in your browser

Help file

Opens up this help file

About

Tells you which BClab version you currently have installed



SHORTCUTS

Ctrl+O	Open file
Ctrl+S	Save file
Ctrl+Q	Quit program
Ctrl+Z	Undo
Ctrl+Y	Redo
Ctrl+M	Read Tune Card
Ctrl+R	Write TuneCard
Ctrl+E	Read from system
Ctrl+W	Verify settings
Ctrl+T	Write to system

F1	Help
F2	Box settings
F3	BCLab settings
F4	Log settings
F5	Sensor settings
F6	3D-view
F7	Main Window
F8	Log Window
F9	Start logg
F10	
F11	Redraw
F12	Setting summary

FILE FORMAT

.cbc	Engine settings file
.cbl	Log file (log data, log settings and engine settings)
.bcc	Password file.
.csv	File with exported log data. Can be read by ex. Excel
.bmp	File with exported log data as a picture.
SA500_1000.ini	PC-program default settings.
SA500_1000_Default_Log_Settings.cbl	Default log settings. Can be opened as a normal log file and edited. By editing this file you can control how the log program will look like at start up.



WORDLIST AND DEFINITIONS

Load	Definition of how much torque the engine tries to create at a specific moment. This is normally measured by MAP, MAF or Throttle position. This load signal together with the RPM signal is normally the base for all the mapping
MAF	Mass air flow, the amount of air that flow in to the engine (gram/sec)
MAP	Manifold absolute pressure, the pressure in the intake manifold.
SmartCard	The type of memory cards all the settings can be stored at (Tune Cards)
TuneCard™	Civinco's name of the smart cards
Chipdrive	Product name of one of the supported SmartCard-readers.
Todos	Product name of one of the supported SmartCard-readers.
Boost	The pressure that the turbo creates. Normally relative to the barometric pressure and therefore sometimes negative and sometimes positive.
RPM	Revolution per minute
ms	Millisecond = 1/1000 second
AFR	Air to Fuel Ratio

2.5D

For some tables, Civinco does not use full 3D maps, but instead one table for load and one for RPM. This is then by the program automatically recalculated as a 3D map. Civinco call this system 2.5D. This means that the user does not have to enter the right data for all the tuning points in a RPM x Load matrix. Instead the user only have to enter values for RPM and Load separately.

Example: If you have a simplified map with 3 x 3 cells looking at 0-2000 rpm, 2001-4000rpm and 4001-6000 rpm and also 3 different Loads. In a full map you normally enter 9 different values, but with 2.5D you enter 3+3 values. (In a 20x20 matrix you only enter 40 values instead of 400 values)

Simplified example

MAP	Fuel depending on Load	Calculated 2.5D values		
2-3 bar	10 ms	$10ms * 1.0 = 10ms$	$10ms * 1.0 = 10ms$	$10ms * 1.1 = 11ms$
1-2 bar	2 ms	$2ms * 1.0 = 2ms$	$2ms * 1.0 = 2ms$	$2ms * 1.1 = 2.2ms$
0-1 bar	0 ms	$0ms * 1.0 = 0ms$	$0ms * 1.0 = 0ms$	$0ms * 1.1 = 0ms$
	Fuel depending on RPM	100 %	100 %	110 %
	RPM	0-2000 rpm	2001-4000rpm	4001-6000 rpm


PWM SIGNALS

PWM means Pulse Width Modulation and is a method to create an analog signal out of a digital signal. This is the most common way to control speeds of valves and engines which



need a little more power. In practical use it's like switching on and off the 12V signal very fast. If it is on half the time and off half the time the engine runs on half speed. So, the signal is set by giving the percentage that the signal is on.

The SA-500 system is grounding the signal, so you supply +12V on the other side. 100% means all the time grounded, and 0% never grounded. The frequency which is used can be selected in the PWM settings, but default is 38.6 Hz.



SA500 system is using PWM to control:

- Boost control valve
- VTEC
- NOS
- Water injection



Upgrade of BCLab

Civinco is all the time releasing the latest software upgrades for free at:
<http://www.civinco.com/downloads> .

Versions and updates of the SA-500/1000 box

Civinco sends a notice to customers if there are any important upgrades that must be made of the system software. You must send the system to Civinco for upgrade.

By connecting to the system with BC-lab and press “INFO” you will get all the information about which version of the software and dataset ID.

Version history of Stand Alone

Product name	ID	Date	FW	BCLab	HW	Note
SA500/1000	200	July 2005		4.0.0 - 4.0.70		
SA500/1000	200	Feb 2006		4.0.0 - 4.0.70	SA500 1.00	Upgraded system with coil adapter
SA500/1000G2	201	July 2006		5.0.1 - 5.0.46	SA500 1.01	4 times more memory, double fuel maps, USB
SA500/1000G2	202	June 2007		5.1.1 - 5.1.34	SA500 1.01	Cold start fuel and increased support for acceleration fuel
SA500/1000G3	203	Dec 2007		5.2.1 - 5.2.25	SA500 1.02 - SA500 1.03	3D ignition upgrade
SA500/1000G3v2	204	Feb 2009		5.3.1 - 5.3.33	SA500 1.03	Deceleration fuel, Autotune
SA500/1000G3v3	205	Mars 2010	3.0.32-	5.4.13-	SA500 1.03	ALS, 3 fuel maps, 3 ignition maps

Product name

The trade name of the system which is on the home page and in marketing material. G1, G, and G3 describes the main generation of the system. G3v1 can be upgraded to G3v3 which is in the same generation, but with some added functionality

Date

Date when the system was first introduced to the market.

Dataset ID

Dataset ID describes which data format all the settings is stored in, when stored to files, to memory cards and in the system itself. When new functions are added, it normally also comes with a new dataset ID.

To be able to use a specific dataset ID you must have the right FW in the system and also the correct BC-lab.

Firmware (FW)

Firmware is the software which is controlling the system itself. Some engines do need a special FW, but in general it is best to have the latest FW.

BCLab version

Version number of your BCLab. It is important that you use the right BCLab, which is working with your particular DatasetID.



HW version


Every system also have a manufacturing hardware version number which is printed on the PCB inside the system.



INSTALLATION OF SA500G3 & SA1000G3

INSTALLING THE SYSTEM

To run an engine which is not connected to the ECU at any way demands only a few connections and this is normally done relatively fast. If you have access to the electrical scheme of the stock ECU the easiest way is then to cut the right cables and solder them into the BC-harness instead.



1. +12V Power supply **pin 24**
 - a. Connect +12V to the box (red wire). Switched by the ignition. **NB: It's important that the power is still on while cranking the engine.** The box doesn't need a lot of power so you can use a thin wire.
 - b. Connect all the ground wires (2-4 wires) to a good grounding point in the cars chassis. There's a lot of power going thru pin no 1, 23 and you want to connect these with short and thick wires.
2. +5V Power supply **pin 2**
 - a. Connect +5V from the box to the sensors that need power
 - i. MAP sensor
 - ii. Throttle position sensor



- iii. Camshaft sensor
 - iv. Crankshaft sensor
- b. Connect ground to the sensors from signal GND pin no 1.
- 3. Fuel **pin 21, 19, 17, 15**
 - a. Connect all the injectors to different pins in the box.
 - b. Connect +12V to the other connections on the fuel injectors. Connect the power supply via a relay that is controlled by the BC-systems ASD output.
 - c. Control the fuel pump thru a similar relay.
- 4. Ignition **pin 13, 11**
 - a. Connect the box to the ignition module (amplifier). (Follow the instructions from the supplier)
 - b. Connect the ignition module with the ignition coil (Follow the instructions from the supplier)
 - c. Connect +12V to the ignition coils and the ignition module. The power supply should go thru a relay controlled by the BC-systems ASD output.
- 5. Crankshaft sensor **pin 14**
 - a. The crankshaft sensor is most often an inductive signal with 2 wires. Connect one wire to the BC-box and the other one to signal GND. Try to use good quality shielded wire and connect the shield near the box.
- 6. Camshaft sensor **pin 22**
 - a. If you have a digital camshaft sensor then connect the signal to the box.
 - b. Make sure that the sensor is connected to a power supply.
- 7. MAP-sensor **pin 6**
 - a. Connect the sensor to the box.
 - b. Make sure that the sensor is connected to a power supply.
- 8. Throttle position sensor **pin 8**
 - a. Connect the sensor to the box.
 - b. Make sure that the sensor is connected to a power supply.
- 9. Coolant temperature sensor **pin 4**
 - a. In most cases the coolant temp sensor is a 2-way resistive sensor that is connected to GND in one end and is measured and powered by the box thru an internal resistance of 3.3 kOhm. Connect pin no 4 to one end.
 - b. Connect the other end to GND.
- 10. Oxygen sensor **pin 10**

You are able to run the engine without the oxygen sensor, but it's very helpful during tuning of the car.

 - a. Connect the signal wire from the oxygen sensor to the BC-box.
 - b. Make sure that the sensor is connected to a power supply and GND.



CONNECTOR SPECIFICATION SA500 G3 v3

In some cases the colour of the wires may occur, but the pin number has never changed through the history.

SApin	Färg	Namn	Info
1	svart	Matarjord GND in	
2	grå	5V ut	<i>Drivning av tex MAP & TPS-sensor</i>
3	orange	Digital 1 ut	* <i>ASD, Varvräkn, Fläkt, Felkod, Programmerbar</i>
4	violett	Motortemp in	
5	brun / grön	PWM 1 ut	** <i>Styrd av AFR, TPS, MAP, Coolant, RPM eller Temp</i>
6	blå	MAP sensor in	
7	gul	Digital 2 ut	* <i>ASD, Varvräkn, Fläkt, Felkod, Programmerbar</i>
8	röd / grön	Trottelpositionsensor in	
9	vit/orange	PWM 2 ut	** <i>Styrd av AFR, TPS, MAP, Coolant, RPM eller Temp</i>
10	röd / gul	Lambdasensor in	
11	svart / grön	Tändkanal B out	
12	grön	Lufttemp in	
13	blå / röd	Tändkanal A ut	
14	blå / vit	Vevaxelsensor in (med partvinnad jord)	
15	brun / grå	Bränsle_D ut	
16	grön / vit	12V battery sens in	<i>oinkopplad= internt kopplad till 12V BAT</i>
17	brun / svart	Bränsle_C ut	
18	vit	Digital 2 in	<i>Hastighet, Bränsle long term adaptive, Ignition cut, extern PWM2 idle air</i>
19	brun / blå	Bränsle_B ut	
20	gul / grön	Digital 1 in	<i>Launch control in</i>
21	brun / gul	Bränsle_A ut	
22	röd / vit	Kamsensor in (med partvinnad jord)	
23	svart	Matarjord GND in	
24	röd	12 V matning in	
	svart/vit	Signaljord ut till sensorer	



CONNECTOR SPECIFICATION BC1000S G3

In some cases the colour of the wires may occur, but the pin number has never changed through the history.

SApin	Colour	Name	Info
Master			
1	svart	Matarjord GND in	
2	grå	5V ut	Drivning av tex MAP-sensor
3	orange	Digital 1 ut	****
4	violett	Motortemp in	
5	brun/grön	PWM 1 ut	*****
6	blå	MAP sensor in	
7	gul	Digital 2 ut	****
8	röd / grön	Trottelpositionsensor in	
9	brun/röd	PWM 2 ut	*****
10	röd / gul	Lambdasensor 1 in	
11	svart / grön	Tändkanal B out	
12	grön	Lufttemp in	
13	blå / röd	Tändkanal A ut	
14	blå / vit	Vevaxelsensor in (med partvinnad jord)	
15	vit/lila	Bränsle_D ut	
16	brun	Batteri 12V sens in	Oinkopplad=internt till 12V
17	vit/brun	Bränsle_C ut	
18	vit/svart	Digital 2 in	* AFR control, Ignition cut
19	vit/blå	Bränsle_B ut	
20	brun/grå	Digital 1 in	* Launch control in
21	vit/gul	Bränsle_A ut	
22	röd / vit	Kamsensor in (med partvinnad jord)	
23	svart	Matarjord GND in	
24	röd	12 V matning in	
	svart/vit	Signaljord ut till sensorer	



SApin	Slave	Colour	Name	Info
1		svart	Matarjord GND in	
2		ej inkopplad		
3		grön/vit	Digital 3 ut	****
4		violett	Motortemp in	** sammankopplad med master i kablage
5		brun/svart	PWM 3 ut	*****
6		*** internt sammankopplad med master		
7		brun/gul	Digital 4 ut	****
8		röd / grön	Trottelpositionsensor in	* analog 6 in, ofta samma som master
9		brun/blå	PWM 4 ut	*****
10		gul / grön	Lambdasensor 2 in	analog 5 in, vänster bank
11		svart/gul	Tändkanal D ut	
12		grön	Lufttemp in	* analog 12 in, ofta samma som master
13		vit	Tändkanal C ut	
14		*** internt sammankopplad med master		
15		vit/orange	Bränsle_H ut	
16		brun	Batteri 12V sens in	Oinkopplad=internt till 12V
17		vit/röd	Bränsle_G ut	
18		vit/svart	Digital 4 in	* kopplas ofta samman med master
19		vit/grå	Bränsle_F ut	
20		brun/grå	Digital 3 in	* Launch control in
21		vit/grön	Bränsle_E ut	
22		röd / vit	Kamsensor in	** sammankopplad med master i kablage
23		svart	Matarjord GND in	
24		ej inkopplad		
		svart/vit	Signaljord ut till sensorer	

SA1000G3 v3 is divided into 2 halves which is called Master (M) and Slave (S), which has its own connector. If you connect to a V-engine, normally you connect one bank to each half of the system. This makes it possible to run individual fuel trim etc on each bank of the engine, if you also have 2 AFR-sensors.



THE BOX FRONT PANEL

There are 4 LEDs above the TuneCard slot. These are from the left:

1. Green power - The BC is powered up
2. Red This LED will light up at pre selected rpm chosen in BCLab, see page [Box settings-"RPM ind"](#)
3. Red Read/Write operation in progress. Also LED for error codes
4. Green steady: TuneCard read/write operation completed. Flashing (two flashes repeatedly): TuneCard read/write operation completed and the slave-PCB data is verified

The button next to the LEDs is used like this:

If the button is held pressed while a TuneCard is inserted the current BC-box data is transferred to the TuneCard, - the TuneCard data is replaced by the data in the BC-box.




CRANK SENSOR

The crank sensor gives information about the position of the crankshaft, and is used to determine ignition and fuel pulse timing.

The most common crank sensor setup is 60-2, but the BC-system supports many different sensors.

The BC-system can handle both inductive and digital signals. An inductive sensor consists of a magnet and a coil that generates a signal when a magnetic material is passing the sensor.

The BC-system detects when the sensor changes polarity. If you are uncertain if the signal you're getting is strong enough then you can use the oscilloscope mode to do a high-speed log of the cam and crank settings and determine if it looks right. With normal logging you are able to check the status of 60-2 error, and check if the error occurs more seldom.



CAM SENSOR

The Cam sensor sends information about the position of the camshaft, and we therefore know the engines intake and combustion cycle. There are two crankshaft rotations per working cycle in a four-stroke engine. Because of this the BC-system can't determine in what position the engine is, based on the crankshaft. The most common is for the cam sensor to send a signal every other crankshaft rotation. The BC-system needs this signal to be run sequentially.

The BC-system can handle both inductive and digital signals.

FUEL INJECTORS

The BC-system is able to run fuel injectors with higher resistance than 6 Ohm (this is normally measured with a multimeter). The system is normally able to run 2 injectors / fuel channel.



IGNITION COILS

The BC-system needs an external igniter (amplifier) to be able to run the ignition coils. The system can be configured in the following ways.

- 4 cyl with 1 coil and distributor
 - SA500G3
 - BC1000S
- 4 cyl with 4 coils
 - SA500G3 waste fire
 - BC1000S direct ignition
- 5 cyl with 1 coil och distributor
 - SA505 G3
 - SA1005 G3
- 5 cyl with 5 coils





- SA1005 G3 coil on plug
- 6 cyl with 1 coil and distributor
 - BC1000S
- 6 cyl with 6 coils
 - BC1000S waste fire
- 8 cyl with 1 coil and distributor
 - BC1000S
- 8 cyl with 4 coils
 - BC1000S waste fire

FIRING ORDER

Civinco stand alone system has 1, 2, 4 resp 5 ignition outputs. The ignition outputs are named to:

SA500G3

A, B (pin M13 resp. M11)

SA505G3

A (pin M13)

SA1000G3

A, B in Master connector (pin M13 resp. M11)

C, D in Slave connector (pin S13 resp. S11)

SA1005G3,

Special for 5 ignition channels.

A, B, C, D, E in Slave connector (pin S21, S19, S17, S15, S11)

The firing order for respective engine model is shown in engine configuration.

All engines with distributor uses channel A, no matter firing order.

Cylinder order for some engines on the market

To understand the firing order, you must first understand how the manufacturer has numbered the cylinders of the engine. Unfortunately this differs a lot between the different manufacturers.

As result of this can two firing orders on the paper, be exactly the same in real life (fire pattern)

Cyl	Manuf.	Schematic picture	Firing order
4	Volvo, BMW, Audi, Saab,		
		Most straight-4s, (Volvo, BMW, Audi, Saab etc)	1-3-4-2
		Some English Ford engines, Ford Kent engine	1-2-4-3
		Yamaha R1 crossplane	1-3-2-4



	WV beetle		1-4-3-2
	Subaru		1-3-2-4
5	Volvo 850, V70, Audi 100		1-2-4-5-3
6	BMW, Volvo		
		BMW, Volvo, Toyota Supra, all straight 6 engines	1-5-3-6-2-4
		Mercedes-Benz M104 engine, Ford 6 cyl straight engines	1-4-2-5-3-6
	Porsche 911		
		Porsche 911	1-6-2-4-3-5
6	Audi		
		Audi 3lit DOHC, Alfa 75	1-4-3-6-2-5
6			
6	Saab		



		Saab 3.0 lit DOHC (B308)	1-2-3-4-5-6
6		<p>Diagram showing 6 cylinders arranged in two rows. The top row has cylinders 2, 4, and 6. The bottom row has cylinders 1, 3, and 5. A vertical line on the left side of the top row is labeled 'Front', and a vertical line on the right side of the top row is labeled 'Back'.</p>	
		GM 60-Degree V6 engine	1-2-3-4-5-6
		GM 3800 engine	1-6-5-4-3-2
8	Porsche, Audi, Ford, BMW	<p>Diagram showing 8 cylinders arranged in two rows. The top row has cylinders 1, 2, 3, and 4. The bottom row has cylinders 5, 6, 7, and 8. A vertical line on the left side of the top row is labeled 'Front', and a vertical line on the right side of the top row is labeled 'Back'.</p>	
		Porsche 928, Ford Modular 5.8l engine, 5.0 HO	1-3-7-2-6-5-4-8
		Ford 5.0lit	1-5-4-2-6-3-7-8
		BMW 740	1-5-4-6-3-7-2-8
		BMW S65	1-5-4-8-7-2-6-3
		Audi 4.2lit DOHC	1-5-4-8-6-3-7-2
8		<p>Diagram showing 8 cylinders arranged in two rows. The top row has cylinders 5, 6, 7, and 8. The bottom row has cylinders 1, 2, 3, and 4. A vertical line on the left side of the top row is labeled 'Front', and a vertical line on the right side of the top row is labeled 'Back'.</p>	
8	GM Northstar only	<p>Diagram showing 8 cylinders arranged in two rows. The top row has cylinders 1, 3, 5, and 7. The bottom row has cylinders 2, 4, 6, and 8. A vertical line on the left side of the top row is labeled 'Front', and a vertical line on the right side of the top row is labeled 'Back'.</p>	
		GM (Northstar only)	
8	GM, Chevrolet, Chrysler	<p>Diagram showing 8 cylinders arranged in two rows. The top row has cylinders 2, 4, 6, and 8. The bottom row has cylinders 1, 3, 5, and 7. A vertical line on the left side of the top row is labeled 'Front', and a vertical line on the right side of the top row is labeled 'Back'.</p>	
		1988 Chrysler Fifth Avenue, Chevrolet Small-Block engine	1-8-4-3-6-5-7-2
		GM LS engine	1-8-7-2-6-5-4-3
10	Chrysler	<p>Diagram showing 10 cylinders arranged in two rows. The top row has cylinders 2, 4, 6, 8, and 10. The bottom row has cylinders 1, 3, 5, 7, and 9. A vertical line on the left side of the top row is labeled 'Front', and a vertical line on the right side of the top row is labeled 'Back'.</p>	
		Dodge Viper V10 (2,4,6,8,10 right side)	1-10-9-4-3-6-5-8-7-2



	BMW	<div style="display: flex; justify-content: space-around;"> ①②③④⑤ </div> <div style="display: flex; justify-content: space-around;"> FrontBack </div> <div style="display: flex; justify-content: space-around;"> ⑥⑦⑧⑨⑩ </div>	
		BMW S85	1-6-5-10-2-7-3-8-4-9

IGNITER

The igniter is a power transistor that can handle the high current and voltage peaks you're getting from running the ignition coils. Another advantage with an external igniter is to be able to isolate the interference by using separate power supply to the igniter and the ignition coils as regards to the BC-system.



One normal pinout of a typical igniter like Volvos are:

1. Output to ignition coil
2. Power ground
- 3.
4. +12Volt supply voltage
- 5.
6. Ignition input from BC-system
- 7.

BOOST CONTROL VALVE

The BC-system handles most PWM-type boost control valves.

IDLE CONTROL VALVE

There are many different types of idle controls, and the BC-system supports PWM-type with both 1 and 2 signals.

OXYGEN SENSOR

The oxygen sensor measures if the engine is running lean or rich. There are mainly two different kinds, narrowband- and wideband oxygen sensors.

Narrow band oxygen sensor

This one generates a voltage between 0 and 1 V which tells you if the engine is running lean or rich. When tuning the fuel so that this signal is pending back and forth the AFR=14.7. This kind of sensor can be used to tune partial load for better fuel economy.

The narrow band sensor is available with different numbers of connection wires (1-4), but the principle is the same.

Some of the wires for the signal and the others to preheat the sensor.

- 1-wire Signal in the wire, GND in the chassis.
- 2-wires Signal in one wire, GND in the other.





- 3-wires Signal in one wire, GND in the chassis, 12V to the heating element in two wires.
 4-wires Signal in one wire, GND in one wire and 12V to the heating element in two wires.

Wide band Oxygen sensor

This sensor is a lot more complicated than the narrow band sensor, and requires special devices to be run. However there's almost always a signal that delivers a voltage that's proportional to the AFR value. There are often special outputs that delivers 0 to 5V depending on the oxygen level, i.e. 0V=AFR 10, 5V=AFR 20. This signal should be connected to the BC-system.

By measuring the AFR you can control the fuel to the exact right AFR value depending on load. On partial load to get the best fuel economy and also maximum load to get AFR=12.5

The BC-system can't run a single wide band oxygen sensor; it must have an aftermarket system built for this purpose.



COOLANT TEMPERATURE SENSOR

The most common is that coolant sensors are resistive and change resistance depending on temperature. This means it has two electrically connections, but the most common is that the sensor is grounded in engine block and therefore only one cable is connected. This single wire should be connected to the BC-system, which is measuring the resistance via an internal pull up resistor to +5V. The internal resistance in the BC-system is 3.3 kOhm, which is supporting temperature sensors with resistance from 100 Ohm up to 10 kOhm.



The most common for temperature sensors is that the resistance (and the Voltage) is decreasing when the temperature is increasing.


INTAKE AIR TEMPERATURE SENSOR (IAT)

Typically the same type as coolant sensors, but more often with 2 wires, where you have to ground one wire your self. In cars with MAF sensors the IAT-sensor is often built in the MAF.

THROTTLE POSITION SENSOR (TPS)

TPS is a sensor which is located at the throttle body, and measure the butterfly angle. Often this is made by a 3 pin rotating potentiometer. This potentiometer is supplied by +5V and signal ground, and gives a signal varying from 0.5-4.5V. If you end up with a signal with "mirrored" behavior, you can often just swap the +5V and ground to have a signal which is increasing with increased throttle.

Modern throttle bodies can also have more signals, like both real signal and mirrored signal.






MAP-SENSOR

MAP is a sensor which is measuring the pressure in the intake manifold. This pressure is maybe the most common to use for tuning, so it is very important that this is mounted correctly. Either you mount the sensor in the engine compartment and connect to the system with wires, or you can have the BC-system delivered with internal MAP-sensor.

Typically the MAP-sensor is supplied with +5V and ground, and then it sends a signal which varies from 0 to +5V depending on pressure.



MAF-SENSOR

A sensor which measure the air flow into the engine. In modern cars it is quite common that the stock PCM uses MAF instead of MAP as load sensor and base for the tuning. The BC-system does not normally use this as load sensor, instead it uses MAP, throttle and temperature.


Typically the MAP-sensor is supplied with +5V and ground, and then it sends a signal which varies from 0 to +5V depending on air flow. At older Volvo and Porsche it can be supplied with +7V instead.



ASD/DME-RELAY

Normally you do not want the fuel pump, coils and injectors to be supplied with battery voltage unless the engine is running. This to make sure the fuel is not flushing if there is an accident.

The BC-system can control such relays with a dedicated output with this function. When the ignition is turned on the ASD output will only be activated 3 seconds until the engine is turning.






KNOCK SENSOR

An knock sensor is a microphone which can detect if the engine is pinging/knocking. Pinging is something you under all cercomstances like to avoid because it is very harmfull, specially at high load. Many modern engines are deliverd with knock sensors, but there are also after market systems to buy.

The BC-sysstem can not hook up with a knock sensor directly, but instead need an aftermarket system which is amplifying the signal first and convert it to a 0-5V signal.



One way to avoid ping is to use higher octane fuel, reduce the boost or reduce the ignition timing. If you reduce the timing it is important to understand that the axhaust gas temperature is increasing.



TUNING WITH SA500G3/1000S G3

Pretuned settings for specific make and models are available. Please contact Civinco for more information.

CHECK ALL THE INPUT SIGNALS

When the system is installed you should start with checking that all the input signals are correct.

- What are the maximum and minimum values.
- Without interference
- Check the cam-and crank signal

(1) Power supply and ASD-function

1. Turn the ignition ON.
2. Check that the ignition coils and fuel pump is powered up for 3 sec, and then shut down. (if there's an ASD-relay connected).

(2) Check the analog input signals

1. Turn the ignition ON.
2. Start logging and select to view the analog signals.
3. Titta på de analoga signalerna och kolla att varierar på rätt sätt
 - a. Try to suck on the MAP-sensor.
 - b. Step on the gas pedal all the way down for a couple of times.
 - c. Heat up the coolant temp sensor.

If you're not sure what kind of voltage the sensors deliver at different pressure, temperatures etc. then it's a good idé to test this and write down the results to be able to do sensor definitions. This also helps you while tuning, if any of the sensor values are unreasonably high or low.

(3) Check the Cam and Crank signals

1. Disconnect the power supply to the fuel pump, injectors and ignition coils.
2. Turn the ignition ON.
3. Start high speed logging.
4. Crank the engine for a few seconds.
5. Stop the high speed logging.
6. Check the cam and crank signals and make sure they look reasonable.
7. Check that the ignition fires correctly with a timing light.

(4) Check the ignition

1. Reconnect the power to the ignition coils, but **not** to the fuel.
2. Turn the ignition ON.
3. Crank the engine for a few seconds.
4. Check that the ignition fires correctly (set on crank ignition) with a timing light. If the ignition fires incorrectly you have to adjust **Crank sensor teeth** and **Crank sensor offset**, see page [Engine setup](#).




AUTOSETUP & FIRST START UP

To create your first map you can use the autoseup guide, which takes you through all settings and let you answer a few questions

You find the guide under **Settings / Auto setup guide**.


To start up the engine is relatively easy, but to get the engine perfectly tuned takes a lot of job. This guide only helps you to start up the engine.

1) Set up the analog sensors




Select your analog sensors. If you miss your sensor in the list, select a standard 0-5V sensor or create your own sensor from datasheets of your engine

2) Select engine (number of cylinders, type of igniton, crank sensor etc.)






3) Decide the size of the fuel map, and which load sensor to use



Select the number of cells you like for RPM and load. Also use the controls to spread out the cells evenly.


4) Decide the size of the ignition map, and which load sensor to use



5) Enter datas of your engine as base for the fuel map

Type of fuel
 Number of injectors
 Fuel pressure
 Shortest injector time
 Target AFR
 Total cylinder volume
 Volumetric efficiency at different RPM
 Highest MAP (1bar = atm)
 Lowest MAP vid motorbroms

Adjust the VE until the "air-power" is close to the truth
 Adjust the fuel injector parameters until the "fuel-power" is close to the truth.





6) Enter data of the engine to get a default ignition map

Enter ignition at full throttle and max RPM

Enter ignition at full throttle and 1000 RPM

Enter degrees of retardation at 1 bar (15 psi boost)

Enter ignition advancing at low load

Auto Setup

Ange efterföljande data för hur du vill att ländmappen ska se ut. Om du använder TPS som bas för ländmappen ska du först se till att ländmappens lastceller sträcker sig mellan minsta och högsta trollepositionsläge.

Värdena som står som default i programmet är valda för att matcha en normal modern 4 cyl motor. Även om du minsta osäker så kan du minska ländmappen med 5-10 grader för att vara på säkra sidan.

Överst måste du vara lyhörd för att motorn inte spikar på fullast, och där rekommenderar vi att du använder någon form av spikdetekteringsutrustning under mappning.

När du är nöjd med dina inställningar trycker du bara 'Generate ignition map'.

Engine data for fuel map calculation

☒ Petrol ☐ E85

Number of fuel injectors: 4
 Fuel injector size [cc/min] @ 3bar: 300
 Fuel pressure [bar]: 3
 Injector offset time [ms]: 1.2
 Desired lambda: 1
 Total engine cylinder volume [cc]: 2300

Engine data for ignition map calculation

Ignition at MAP=1 bar and Max rpm: 34
 Ignition at MAP=1 bar and 1000 rpm: 20
 Ignition retard per 1 bar (15psi) boost: 10
 Ignition advance at vacuum: 10

Generate ignition map

	idle	mod	maxP	max
RPM	800	2000	4000	6500
VE [%]	65	70	80	75
Estimated maximal MAP [bar]	1.0			
Lowest MAP [bar]	0.2			

The air will be enough for: 159hp
 The fuel is enough for: 224hp

Max fuel pulse length at max MAP: 14.3 ms

Sequential fuel
 Generate fuel map

Previous step Restart Next step

7) AFR control

Tuning settings

AFR Control On/Off
☐ Off ☒ On

AFR control settings

AFR sensor type: ☐ Narrow ☒ Wide
 AFR sensor low voltage: ☒ Rich ☐ Lean

AFR control start delay: 60 s
 AFR control speed at idle, Sum (I): 5

AFR control minimum load sensor: ☒ MAP ☐ Throttle and idle RPM
 AFR control min. Load to be active: 0.40 bar
 AFR mapping Load sensor: MAP
 AFR control max Load to be active: 1.00 bar
 AFR control max RPM to be active: 4000 rpm
 Coolant temp. to start AFR control: 50.2 C

Auto tune (long term adaptive) settings:
☒ Off ☐ On/Off controlled by digital 2 in ☐ Always On

Number of AFR sensors (when using SA1000 only):
☐ 1 connected to slave ☒ 2

Ignition settings: PVM outputs: **AFR control** Idle settings: Temp corrections:
 Analog settings: Limits / Warnings: Engine setup: Fuel acceleration: Fuel settings:

Auto Setup

Wide band sensor
 Use Fuel AFR table to be used

The idle control only active between a low load limit and

AFR Control
 Försökta dig om att inställningarna för ländmappen matchar det du tänkt dig. Default är det inställt på att använda short term ländmappen när motorn uppnått en viss temperatur. Du kan även slå av 'closed loop' på fullast

Previous step Restart Next step

8) Table for AFR target

Direct communication
 < COM Port info >
 Verify Info
 Read settings Write settings
 SA-box TuneCard

Set AFR voltage, based on selected load signal

Volt	bar	Lam
0.00	0.00	1.00
0.31	0.25	1.00
0.63	0.40	1.00
0.94	0.55	1.00
1.25	0.70	1.00
1.56	0.87	1.00
1.88	1.03	0.86
2.19	1.19	0.86
2.50	1.34	0.86
2.81	1.50	0.86
3.13	1.66	0.86
3.44	1.81	0.86
3.75	1.97	0.86
4.06	2.13	0.86
4.38	2.29	0.86
4.69	2.44	0.86
5.00	2.59	0.86

Auto Setup

Lambda Load sensor: MAP - MPX 2.5bar
 VB_LCI_FDEF_Lam


Mål lambda vid olika last
 Normalt sett vill man styra till lambda=1 på låglast och tunning, och lambda=0.85 på högre och full last

Previous step Restart Next step


2nd Fuel MAP 2nd Fuel RPM AFR Control 3D Main MAP PVM/Boost/Idle
 General Ignition Fuel PVM/Boost/Idle




9) Temperature compensation



10) Start up settings




11) Acceleration fule







12) Idle adjustment



13) Digitala input




14) Digitala output







15) PWM output



16) Warning levels and error codes




17) Test the polarity of cam and crank sensor





18) Enter the crank sensor distance to TDC



CREATE YOUR FIRST TUNING PARAMETERS

Fuel injectors

If the fuel injectors are dimensioned correctly they will be open 80% of the time on maximum load and RPM. A rule of thumb is that 60 lbs/h is enough for 100hk. If you have an engine with 200 hk and 4 cyl, then each fuel injector should deliver 30 lbs/h.

Fuel map

On maximum load the injectors delivers about 16 ms of fuel.
While idling the same engine often requires about 2.5 - 3.5 ms.
In between these two you could start with letting the fuel vary linear.


Fuel Main 3D map															
Set fuel depending on RPM and Load															
Fuel 3D Load sensor: MAP - SAAB_MAP 2.5bar [bar]															
	0	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	
0.12	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
0.22	3.2	3.0	2.5	2.5	2.6	2.6	2.6	2.6	0.0	0.0	0.0	0.0	0.0	0.0	0.0
0.32	3.6	2.8	2.7	2.8	2.9	3.0	3.0	3.1	3.3	3.4	3.4	3.4	3.4	3.4	3.4
0.42	3.4	3.2	3.4	3.5	3.6	3.6	3.6	3.6	3.8	4.0	4.2	4.2	4.2	4.2	4.2
0.52	4.8	4.8	4.8	4.7	4.7	4.7	4.7	4.7	4.7	4.7	4.7	4.7	4.7	4.7	4.7
0.61	5.0	6.0	5.7	5.5	5.3	5.4	5.4	5.4	5.4	5.5	5.5	5.5	5.5	5.5	5.5
0.71	6.1	6.1	6.3	6.1	6.0	6.3	6.3	6.4	6.4	6.5	6.5	6.5	6.5	6.5	6.5
0.81	7.5	7.4	7.4	7.0	7.0	7.3	7.3	7.4	7.4	7.5	7.5	7.5	7.5	7.5	7.5
0.91	9.8	9.6	9.3	8.5	8.6	8.9	8.9	9.0	9.1	9.2	9.2	9.2	9.2	9.2	9.2
1.01	10.8	10.2	9.8	9.2	9.5	9.7	9.9	10.0	10.0	10.2	10.2	10.2	10.2	10.2	10.2
1.11	11.9	11.1	10.7	10.2	10.6	10.8	11.0	11.1	11.1	11.3	11.3	11.3	11.3	11.3	11.3
1.20	12.7	11.9	11.4	11.4	11.5	11.8	11.8	12.0	12.1	12.3	12.3	12.3	12.3	12.3	12.3
1.30	14.0	13.1	12.6	12.7	12.8	13.0	13.1	13.3	13.4	13.6	13.6	13.6	13.6	13.6	13.6
1.40	14.9	14.1	13.5	13.3	13.7	14.1	14.2	14.3	14.3	14.7	14.7	14.7	14.7	14.7	14.7
1.50	16.1	15.3	14.6	14.3	14.8	15.1	15.5	15.6	15.5	15.8	15.8	15.8	15.8	15.8	15.8
1.60	18.5	17.7	16.4	17.1	17.5	17.8	18.1	18.2	18.3	18.6	18.6	18.6	18.6	18.6	18.6



Cold start fuel


A cold engine often requires 30-50% choke fuel to start up.

If you running on ethanol and the engine is cold (<50F), you also need a lot of extra snapps fuel when cranking, 200ms at 20F is not strange.



Startup fuel

About 15% extra fuel at start which is slowly reduced during the first 15 seconds is good.






Accelerationsrikning

Acceleration fuel

Threshold 0,29 V/samp	Threshold fuel 1,50 ms	Low RPM 1000 RPM	RPM AE-fuel % 100 %
High load change 1,25 V/samp	High load fuel 3,00 ms	High RPM 4000 RPM	RPM AE-fuel % 150 %
Sustain 12 0,24 s@30Hz		View 3D graph	

The amount of acceleration fuel an engine needs, varies a lot and can only be tested to find the right tuning. This is an example that shows the principle, and how to tune in the corners in the map.



Below the threshold level there will not be any acceleration fuel.

Just at the threshold level it will be 12 pulses with each 1.5 ms.

Just at the threshold level, but at high rpm it will be 12 pulses with each $1.5 \times 150\% = 2,29$ ms.



Ignition map

The ignition is mostly based on the RPM. More advanced ignition at higher RPM. E.g. 15 degrees (BTDC) while idling, up to 35 degrees on high RPM.

You also retard the ignition (delay the ignition) at higher pressure (higher load). Typically you increase the timing 5-10 degrees at low load compared to full load

	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500
0.12	24,0	22,0	25,2	27,2	29,0	30,8	31,4	32,4	33,4	35,2	37,0	39,0	41,0
0.32	24,0	22,0	25,2	27,2	29,0	30,8	31,4	32,4	33,4	35,2	37,0	39,0	41,0
0.52	24,0	22,0	25,2	27,2	29,0	30,8	31,4	32,4	33,4	35,2	37,0	39,0	41,0
0.71	24,0	22,0	25,2	27,2	29,0	30,8	31,4	32,4	33,4	35,2	37,0	39,0	41,0
0.91	18,6	16,6	19,8	21,8	23,6	25,4	26,0	27,0	28,0	29,8	31,6	33,6	35,6
1.11	16,2	14,2	17,4	19,4	21,2	23,0	23,6	24,6	25,6	27,4	29,2	31,2	33,2
1.30	17,0	15,0	18,2	20,2	22,0	23,8	24,4	25,4	26,4	28,2	30,0	32,0	34,0
1.50	15,4	13,4	16,6	18,6	20,4	22,2	22,8	23,8	24,8	26,6	28,4	30,4	32,4
1.70	13,8	11,8	15,0	17,0	18,8	20,6	21,2	22,2	23,2	25,0	26,8	28,8	30,8
1.89	12,2	10,2	13,4	15,4	17,2	19,0	19,6	20,6	21,6	23,4	25,2	27,2	29,2

Other settings

Read all the pages about settings and make sure that everything looks reasonable.

FIRST ENGINE STARTUP

(1) Startup

1. Reconnect all the power supply.
2. Start the engine.
3. If the engine does not start there is either the ignition or the fuel that is the problem.
 - a. Smell if there is a lot of fuel in the exhaust. This can be a sign that it is too rich.
 - i. Reduce the fuel in the main map or the cold start fuel.
 - b. If it does not smell fuel at all, there could be a too lean problem
 - i. Check if the fuel pump is on
 - ii. Check if it clicks in the fuel injectors when cranking
 - c. If it seems to be good with the fuel, check the ignition
 - i. Remove one spark plug cable, and mount a spark plug in the free air. Make sure the plug is grounded to the engine, and crank the engine. The spark should go every 2nd revolution. If it does not check power and cables.
 - ii. If it is a newly built engine, it is also easy to by mistake connect the wrong ignition cable to the wrong spark plug.