


BC-box, Microfit24



| Microfit connector BC500 Volvo 5-cyl | | | | |
|--------------------------------------|-------------|--------------|--------------------------------|--|
| 1 | black/green | GND | Connect to Chassi | |
| 2 | grey | 5v out | Connected to MAP sensor | |
| 3 | | | | |
| 4 | | | | |
| 5 | violett | PWM | Connect to Boost control valve | |
| 6 | green/red | ANALOG3_IN | Connected to MAP sensor | |
| 7 | orange/blue | ANALOG 2_OUT | MAF signal to ECU | |
| 8 | green/blue | ANALOG 2_IN | From MAF sensor | |
| 9 | orange | ANALOG1_OUT | | |
| 10 | green | ANALOG1_IN | | |
| 11 | blue/yellow | FUEL_E_OUT | To fuel injector | |
| 12 | blue/white | FUEL_E_IN | From ECU fuel signal | |
| 13 | blue/red | IGNITION OUT | To external igniter | |
| 14 | white | IGNITION IN | From ECU igniter signal | |
| 15 | gul/svart | FUEL_D_OUT | To fuel injector | |
| 16 | vit/svart | FUEL_D_IN | From ECU fuel signal | |
| 17 | gul/brun | FUEL_C_OUT | To fuel injector | |
| 18 | vit/brun | FUEL_C_IN | From ECU fuel signal | |
| 19 | gul/grön | FUEL_B_OUT | To fuel injector | |
| 20 | vit/grön | FUEL_B_IN | From ECU fuel signal | |
| 21 | gul/röd | FUEL_A_OUT | To fuel injector | |
| 22 | vit/röd | FUEL_A_IN | From ECU fuel signal | |
| 23 | svart | GND_POWER | Connect to Chassi | |
| 24 | röd | +12Vin | Connect to +12V | |