



Ignition : Pin 11, 12, 13, 14:

It's possible to control 2 ignition modules at the same time, IGNITION_A and IGNITION_B with their in- and outputs. If only one ignition channel is required, then IGNITION_B can be used for other purposes such as: a 5th fuel channel or control of the boost valve.

In many cases there is no need to tune the ignition, in such cases it's sufficient to only sense the rpm. This signal can be from the ignition system, the cam sensor or the crank sensor. Depending on the used signal you may have to connect an amplifier to achieve the correct voltage level.

- 12, 14 Ignition signal inputs to the BC-box from the ECU. The ignition signal shall be connected to the BC-box instead of the ignition module.
- 11, 13 Ignition outputs from the BC-box to the ignition modules (The BC-box cannot drive ignition coils directly without an ignition module). The ignition modules are connected here instead of to the ECU.

Analog signals: pins 6, 8, 10, 7, 9:

- 10, 8, 6 0-5V analog signals Analog1-3. Normally used for measuring Manifold absolute pressure, Mass airflow, knock sensor, throttle position or temperature. The BC-box can use all these signals to tune fuel, boost, ignition etc. in the BCLab software.
- 9 Analog1-output, an analogue output signal which can be voltage limited. It can be used to hide the high MAP or Mass airflow value from the ECU. The output voltage is the same as the input voltage at pin8(analog1) up to a certain maximum value. Any input above this maximum value will only produce that maximum output value. The maximum value is selected in BCLab at page Analog out-Analog1 out.
- 7 Analog2-output. This output can be controlled in three ways:
The output can be a function of the Analog2 input value. For every input there will be a certain output according to how you have tuned this function in BCLab. The output can be voltage limited in the same manner as analog1.
When controlling the boost via PWM_IN/OUT (pins 11,12) this signal can be voltage limited in a smarter way called limit trim.

Driver outputs: pins 5,11:

The boost valve is controlled by a PWM output. Which pin you use for this is selected in the BCLab-Configurations. The PWM output can also be used to control other devices compatible with the PWM-type output (lamps, valves, motors etc.) The outputs can handle 3 Amps.

- 11 PWM output. Normally used to control the boost valve when the ECU boost control signal is connected to the PWM_IN BC-box input.
- 5 PWM output. Can be used to control the boost valve.

PWM input: pin 12:

- 12 PWM input. Can be used to connect the ECU boost control signal to the BC-box. This is used for logging purposes or when you wish to use the Analog2-out "limit trim" function.